





ITEM NAME / NOM D'ITEM: KEPPEL SWIVEL DINING CHAIR
ITEM# / NO. ITEM: 110842/110843

PARTS LIST / LISTE DES PIÈCES


(1)	(2)	(3)
 ×1	 ×1	A. M6 x 20MM  x4 B. Ø7MM  x4 C. Ø7MM  x4 D. 4MM  x1

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE

I



II



Please use the attached adjustable footglides to level the chair on uneven surface.