


ASSEMBLY INSTRUCTIONS


Dining Chair



N752P346006


IMPORTANT NOTE:

- 1.Place all parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- 2.Before you begin, kindly follow the assembly instructions step by step.
- 3.Do not tighten all screws and bolts until the bench is fully set-up.
- 4.Please do not return to store, contact the seller if you have any troubles with this product.




Part List

① x1




② R x1




③ L x1



④ x1




⑤ x1



Hardware List


A



M6 x 50

BOLT (8 pcs)


B



M6

SPRING WASHER (8 pcs)


C



M6

FLAT WASHER (8 pcs)

D



M4 x 32

CSK SCREW (4 pcs)

E



M8 x 30


WOOD DOWEL (4 pcs)

F




M4


ALLEN KEY (1 pc)




Screw Driver Not Provide


Step 1




A		4 pcs	B		4 pcs
C		4 pcs	E		2 pcs
F		1 pc			

Step 2




A		4 pcs	B		4 pcs
C		4 pcs	E		2 pcs
F		1 pc			

Step 3



D



4 pcs



Screw Driver Not Provide

Step 4

