

ASSEMBLY INSTRUCTION

GY-266

Ax1




Seat

Ex8



Spring washer

Bx2



Front leg


Fx8



M8x55mm

Screw

Cx2



Front leg

Hx1



M8



Allen key

Dx8





Flat washer

①




Tighten all the screws to 80% of maximum tightness

②




Tighten all the screws to 80% of maximum tightness

③



Close the zipper of bottom Non-Woven fabric.

④



Adjust the chair so that it is level, then fully tighten all the screws.

WARNING:

DO NOT STAND ON THE PRODUCT, DO NOT USE THIS PRODUCT AS A STEP LADDER.

DO NOT USE THIS PRODUCT UNLESS ALL BOLTS, SCREWS AND KNOBS ARE FIRMLY SECURED.

PLEASE DO NOT USE KNIFE TO OPEN ANY PARTS OF THE BOX OR PRODUCT.