


INSTRUCTION MANUAL



Kids Outdoor Poly Adirondack Rocking Chair
with Side Table 3-Piece Set

V1.0


TABLE OF CONTENTS

ASSEMBLY INSTRUCTIONS

Kids Outdoor Poly Adirondack Rocking Chair..... 3
with Cup Holder

Kids Outdoor Poly Adirondack Side Table..... 10

INSTRUCTION MANUAL




Kids Outdoor Poly Adirondack Rocking Chair
with Cup Holder

! CARE & MAINTENANCE


Please keep these instructions for your future reference.

- Be careful when assembling, avoid damaging the painted surface.
- Clean the chair with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tightening screws.)
- Please do not exceed the weight limitations of this item.


TOOLS REQUIRED




HARDWARE



PARTS




PARTS



PRODUCT ASSEMBLY - OVERALL VIEW

Look at following overall view of this chair and learn the exact position of each part to be assembled.




PRODUCT ASSEMBLY

1

Pick out **Part C Left Chair Leg** and **Part H Rocking Base** from the package.

Attach **Part C Left Chair Leg** to **Part H Rocking Base** as below with 1 pc of **Hardware #2 Screw**.


Do the same to attach **Part D Right Chair Leg** to another **Part H Rocking Base** with 1 pc of **Hardware #2 Screw**.



2

Attach the combined leg **Part (C+H)** to **Part B Chair Seat** with 2 sets of **Hardware #4 Bolt**, **#6 Washer** and **#7 Nut** as well as 1 set of **Hardware #3 Bolt**, **#6 Washer** and **#7 Nut**.


Pay attention not to tighten the bolts too much. Only tighten by about 70%.



PRODUCT ASSEMBLY


3

Attach another combined leg **Part (D + H)** to **Part B Chair Seat** with 2 sets of **Hardware #4 Bolt**, **#6 Washer** and **#7 Nut** as well as 1 set of **Hardware #3 Bolt**, **#6 Washer** and **#7 Nut**.



4


Attach **Part F Left Chair Arm** to **Part C Left Chair Leg** with 1 set of **Hardware #3 Bolt**, **#6 Washer** and **#7 Nut**.



PRODUCT ASSEMBLY


5

Attach **Part G Cup holder** to **Part E Right Chair Arm** with 1 pc of **Hardware #5 Bolt**.



6

Attach **Part E Right Chair Arm** with cup holder to **Part D Right Chair Leg** with 1 set of **Hardware #3 Bolt, #6 Washer** and **#7 Nut**.




PRODUCT ASSEMBLY

7

Place **Part A Chair Backrest** between two arms as below.

Attach **Part A Chair Backrest** to **Part B Chair Seat** with 2 pcs of **Hardware #1 Screw**.


Attach **Part A Chair Backrest** to **Part F Left Chair Arm** and **Part E Right Chair Arm** with 2 pcs of **Hardware #2 Screw**.




8

Check and tighten all the bolts and screws again to ensure the chair is steady enough.

Enjoy the chair now.



INSTRUCTION MANUAL




Kids Outdoor Poly Adirondack Side Table

! CARE & MAINTENANCE

Please keep these instructions for your future reference.

- Be careful when assembling to avoid damaging the top surface.
- Clean the table with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use. Do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tightening screws.)
- Please do not exceed the weight limitations of this item.

TOOLS REQUIRED



**TABLE
50 LBS
CAPACITY**



**1 PERSON
ASSEMBLY**



**UP TO 20 MIN.
ASSEMBLY**

HARDWARE

1

SCREW

M6 x 55mm




12 PCS

PARTS

A


TABLE TOP WITH APRON



1 PC

B


TABLE LEG



4 PCS

C


RAIL I



2 PCS

D


RAIL II



2 PCS

PRODUCT ASSEMBLY – OVERALL VIEW

Look at the overall view of this table and learn the exact position of each part to be assembled.




PRODUCT ASSEMBLY

1

Insert **Part C Rail I** into the mortise of **Part B Table Legs** and secure it with 1 pc of **Hardware #1 Screw**.

Do not tighten screws too much at this stage.




PRODUCT ASSEMBLY

2


Attach another **Part B Table Legs** to **Part C Rail I** with 1 pc of **Hardware #1 Screw**.

Do the same to attach another set of Part B and Part C.



3


Loosely attach the combined Part B and Part C to the aprons of **Part A Table Top** with 2 pcs of **Hardware #1 Screw**.



PRODUCT ASSEMBLY


4

Attach the other combined Part B and Part C to the aprons of **Part A Table Top** with 2 pcs of **Hardware #1 Screw**.




5

Place the other 2 pcs of **Part D Rail II** between **Part B Table Legs** and attach them with 4 pcs of **Hardware #1 Screw**.



6

Tighten all the screws. Turn over the table and enjoy it now.



CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.