


Notice:

- 1. Follow the installation instructions. Please confirm all accessories are preset before installation.
- 2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled.
- 3. If you encounter any problems during installation, please contact our customer service.
- 4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.



Recommended installers:2



Put a carpet on the floor before unpacking



Estimate installation time: 30minutes

PART LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
A		X1	G		X1
B		X1	H		X1
C		X1			X4
D		X1	J		X2
E		X1	K		X1
F		X1	L		X1

HARDWARE LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
1	Ø8*30mm	X22+2	7		X4
2		X20+2	8	Ø3*15mm	X32+3
3		X20+2	9		X8
4	@MMMMM Ø1/4"*2"	X2	10		X1
6		X8	1		X2
6	Ø3*12mm	X48+4			


ASSEMBLY INSTRUCTIONS A , . D \bigcirc (\mathbf{K}) J E \bigcirc **(C)** B \bigcirc

4













ASSEMBLY INSTRUCTIONS B 1PC € 1PC F 1PC © 1PC 3 6PCS ① 6PCS **(G**) •3 (1) (E) \bigcirc 3 \bigcirc E \bigcirc **B** 7




1)6PCS




















Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.

Adjustment range: 4mm

Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm


Up-Down Direction Adjustment:


Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm



Common Door Panel Issues:





The door panels are not coplanar

panels is too large

