


POUNDEX®

PRE-ASSEMBLY TIPS


We get it - building furniture isn't always easy! But have no fear, helpful hints are here. Our assembly tips and tricks will have you enjoying that new furniture in no time. Let's get construction ready to rock!




















FLAT SURFACE

Place on a level surface with furniture legs evenly contacting the floor.








POUNDEX®

ASSEMBLY SAFETY STEPS



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




POSITIONING

Insert all hardware and parts in the correct holes.




Use hand tools unless the manual specifies power tools.




TIGHTENING

Only tighten bolts when the step is fully completed.



INSTRUCTIONS

Keep the manual and tools for future maintenance needs.



MAINTENANCE

Check for loose joints after 2 weeks and re-tighten every 6 months.

DISCLAIMER:

It is the user's responsibility to properly maintain the furniture over its lifetime. Hardware such as screws, bolts, and other fasteners may naturally loosen over time with normal use of the product. This can lead to instability if the furniture is unable to adequately support the intended weight capacity. To prevent injuries, following the maintenance instructions is key to ensuring product safety and longevity.

ASSEMBLY INSTRUCTIONS

Dimensinons: 41.5"W x 41.5"D x 36"H

Item No: F2633


Description: COUNTER HEICHT TABLE


N <u>o</u>	LIST OF PARTS	Q'TY
1	Table Top	1pc
2	Table Legs	4pcs

N <u>o</u>	LIST OF HARDWARE		
A	Bolt	Ø5/16" x 63.5 mm	8pcs
В	Lock Washer	Ø5/16" x 10D x 1.1mn	8pcs
С	Flat Washer	Ø5/16 " x 19D x 2mm	8pcs
D	Allen Wrench	58 x 4mm	1pc

STEP 1

Please remove wood block panel at each corner before assembly the leg





ASSEMBLY INSTRUCTIONS

Dimensinons: 19"W x 22.5"D x 42"H

Item No: F2633

Description: HIGH CHAIR

N <u>o</u>	LIST OF PARTS	Q'TY
1	Chair Back	1pc x 4
2	Seat	1pc x 4
3	Front Leg (L & R)	2 pcs x 4
4	Side Stretcher	2 pcs x 4
5	Front Stretcher	1pc x 4

N <u>o</u>	LIST OF HARI	Q'TY	
A	Bolt	Ø1/4" x 38 mm	2pcs x 4
В	Bolt @	Ø1/4" x 63.5 mm	4pcs x 4
С	Bolt	Ø1/4" x 75 mm	4pcs x 4
D	Lock Washer	Ø1/4" x 10D x 1.1mm	10pcs x 4
Е	Flat Washer	Ø1/4 " x 19D x 2mm	10pcs x 4
F	Allen Wrench	58 x 4mm	1pc x 4
G	Screw ************************************	M4 x 38mm	6pcs x 4

