



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

222526
Bench

ITEM: 222526

COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES


PART IDENTIFICATION

A SEAT



1PC

B SHELF



1PC

C LEG



4PCS


HARDWARE IDENTIFICATION

1	BOLT (5/16 x 50mm - BLK)		12PCS
2	LOCK WASHER (1.6 x 14mm - BLK)		12PCS
3	FLAT WASHER (2 x 19mm - BLK)		12PCS
4	ALLEN WRENCH (M5 x 65mm - BLK)		1PC


ITEM: 222526

ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2




STEP 3 COMPLETE



ITEM: 222526

COASTER
FINE FURNITURE



Note: Dimension tolerance $\pm 5\%$