

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

122509 Counter Stool

ITEM: 122509

ASSEMBLY INSTRUCTION



ASSEMBLY TIPS:

- 1. Remove hardware form box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING:

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A SEAT AND BACK

B LEG FRAME

2PCS

C STRETCHER

2PCS

HARDWARE IDENTIFICATION

			•
1	BOLT (Ø1/4" x 35mm - RBW)		6PCS
2	LOCK WASHER (Ø5/16" x 13mm - RBW)		6PCS
3	FLAT WASHER (Ø5/16" x 19mm - RBW)		6PCS
4	PAN HEAD SCREW (Ø4" x 28mm - RBW)	() -mmm >	4PCS
5	ALLEN WRENCH (M4 x 59mm - RBW)		1PC

NOTE:


Phillips head screw driver is required in the assembly process. However, manufacturer does not provide this item.

ITEM: 122509


ASSEMBLY INSTRUCTION

COASTER


STEP 1




STEP 2



STEP 3




STEP 4
COMPLETE



PAGE 3 OF 3

ITEM: 122509





Note: Dimension tolerance ±5%