



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

193732
Side Chair

ITEM: 193732

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION

A BACK FRAME



1PC

B SEAT CUSHION WITH FRAME



1PC

C LEFT FRONT LEG



1PC

D RIGHT FRONT LEG



1PC

E LEFT SIDE STRETCHER



1PC


F RIGHT SIDE STRETCHER



1PC


HARDWARE IDENTIFICATION

1 LONG BOLT WITH WASHER
(M6 x 70mm - BLK)



8PCS

2 SHORT BOLT WITH WASHER
(M6 x 45mm - BLK)



3PCS

3 PAN HEAD SCREW
(M5 x 38mm)



4PCS

4 ALLEN WRENCH
(M4 x 55mm - GD)



1PC

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: **193732**

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ITEM: **193732**

ASSEMBLY INSTRUCTIONS


STEP 3



STEP 4 COMPLETE



ITEM: **193732**



Note: Dimension tolerance $\pm 5\%$