# Assembly Instructions

Caution: You must read this before you proceed

#### Care & Maintenance



Not for commercial use. For residential use only.



 Furniture may scratch floors. We recommend using furniture pads to protect your floors.



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



 Do not write on furniture without a padded barrier to protect the surface.



• Do not place furniture outside . For indoor use only.



 Stains may be removed with mild soap solution and damp cloth.



Children should not climb or jump on the furniture.



 Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in carton for hardware packs and legs. Sets often ship in multiple boxes and may arrive a day or two apart.




Parts List				
Label	Picture	Description	QTY	
Α		BACK LEG	1	
В		BOX SEAT	1	
С		FRONT LEG	2	
D		SEAT	1	


Parts List				
Label	Picture	Description	QTY	
1		JCBC SCREW (M6*90MM)	4+1	
2		JCBC SCREW (M6*35MM)	2+1	
3		HEX NUT	4+1	
4		FLAT WASHER  SMALL  (1/4")	6+1	
5		SPRING WASHER  SMALL  (1/4")	6+1	
6		FLAT WASHER BIG (5/16")	4+1	
7		SPRING WASHER BIG (5/16")	4+1	
8	-accecec_(-}	PANHEAD SCREW (M4*32MM)	4+1	
9		ALLEN KEY (M4)	1	
10		SPANNER	1	

## **Assembly Preparation**


## Before Beginning Assembly:















- Read instructions, cover to cover.
- Have 2 adults on hand for assembly.
- Do not assembly on flooring or carpet.
- Assembly on a clean non-marring surface (packing foam).
- Save all packaging until finished.

## **Assembly Steps**

#### Overview




This Dining Chair has multiply parts.


To give anoverview of the Dining Chair, the above picture is to help you put the various parts into perspective.

Please read through the instructions below to familiarise yourself with the parts and steps before assembly.


Note: it is recommended that you have an adult partner to assist during the entire assembly process.




Open the carton and place all parts onto a clean, non-marring surface. Use Allen Key (9) to secure Box Seat (B) to Back Leg (A) with Jcbc Screw (2), Spring Washer (5) and Flat washer (4).



Use Allen Key (9) to secure back corner of the Box Seat (B) to Back Leg (A) with Jcbc Screw (1), Spring Washer (5) and Flat Washer (4).



Remove the screw cap on the Front Leg (C) before installing it. Use Spanner (10) to secure Box Seat (B) to Front Leg (C) with Hex Nut (3), Spring Washer (7) and Flat Washer (6).



Secure Box Seat (B) to seat (D) using Panhead Screw (8). Your dining chair is ready to use. This dining chair can only use on a flat, level surface.