

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

193731 (B1&B2) *Dining Table*

ITEM: 193731(B1&B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A TOP



1PC

B2 (BOX 2)

B LEG FRAME



2PCS

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 193731(B1)

1 BOLT WITH WASHER
(M6 x 45mm - BLK)



16PCS

PAN HEAD SCREW
(M4 x 32mm)



4PCS

3 ALLEN WRENCH (M4 x 55mm - GD)



1PC

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 193731(B1&B2)


ASSEMBLY INSTRUCTIONS

STEP 1





STEP 2



STEP 3 COMPLETE






COASTERFURNITURE.COM

PAGE 3 OF 3

ITEM: 193731(B1&B2)





Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

193732 Side Chair

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

Α	BACK FRAME		1PC
В	SEAT CUSHION WITH FRAME		1PC
С	LEFT FRONT LEG	● LEFT SIDE FACING	1PC
D	RIGHT FRONT LEG	☐ RIGHT SIDE FACING	1PC
E	LEFT SIDE STRETCHER	◆ LEFT SIDE FACING BACK ◆	1PC
F	RIGHT SIDE STRETCHER	RIGHT SIDE FACING BACK ①	1PC
	HARDWARE ID	ENTIFICATION	
1	LONG BOLT WITH WASHER (M6 x 70mm - BLK)		8PCS
2	SHORT BOLT WITH WASHER (M6 x 45mm - BLK)		3PCS
3	PAN HEAD SCREW (M5 x 38mm)		4PCS
4	ALLEN WRENCH (M4 x 55mm - GD)		1PC

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ASSEMBLY INSTRUCTIONS

COASTER

STEP 1




STEP 2




ASSEMBLY INSTRUCTIONS

STEP 3






STEP 4 COMPLETE





COASTERFURNITURE.COM





Note: Dimension tolerance ±5%