

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

193610(B1&B2) Dining Table

ITEM: 193610(B1&B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A TOP



1PC

B2 (BOX 2)

B LEG FRAME



3PCS

C LEG FRAME SUPPORT



3PCS

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 193610(B1)

1 BOLT WITH BIG WASHER (M6 x 50mm - BLK)



12PCS

2 BOLT WITH SMALL WASHER (M4 x 50mm - BLK)



6PCS

3 ALLEN WRENCH (M4 x 55mm - GD)



1PC


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: 193610(B1&B2) ASSEMBLY INSTRUCTIONS

COASTER

STEP 1



STEP 2




COASTERFURNITURE.COM


ITEM: 193610(B1&B2) ASSEMBLY INSTRUCTIONS



STEP 3



STEP 4 COMPLETE




PAGE 4 OF 4

COASTERFURNITURE.COM

ITEM: 193610(B1&B2)





Note: Dimension tolerance ±5%

COASTERFURNITURE.COM



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

193612 Side Chair

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

| A | BACK FRAME | | 1PC |
|---|-------------------------|----------------|------|
| В | SEAT CUSHION WITH FRAME | | 1PC |
| С | LEFT FRONT LEG | 6 1 0 | 1PC |
| D | RIGHT FRONT LEG | To R 0 | 1PC |
| E | SIDE STRETCHER | (5 | 2PCS |

HARDWARE IDENTIFICATION

| 1 | LONG BOLT WITH WASHER (M6 x 90mm - BLK) | | 4PCS |
|---|--|-----------|------|
| 2 | MEDIUM BOLT WITH WASHER (M6 x 60mm - BLK) | | 4PCS |
| 3 | SHORT BOLT WITH WASHER (M6 x 50mm - BLK) | | 3PCS |
| 4 | PAN HEAD SCREW (M5 x 38mm - BLK) | () | 4PCS |
| 5 | ALLEN WRENCH (M4 x 55mm - GD) | | 1PC |

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ASSEMBLY INSTRUCTIONS

STEP 1






STEP 2




ASSEMBLY INSTRUCTIONS

COASTER

STEP 3




STEP 4 COMPLETE









Note: Dimension tolerance ±5%