

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

193820(B1&B2) *Dining Table*

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

<u>B1 (BOX 1)</u>

А ТОР



1PC

B MOUNTING PLATE (PRE-ATTACHED TO TOP)



1PC

B2 (BOX 2)

C LEG (L) WITH LABEL "1"



1PC

D LEG (R) WITH LABEL "1"

1PC

E LEG (L) WITH LABEL "2"

1PC

1PC

F LEG (R) WITH LABEL "2"

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 193820 (B1)


1	ALLEN WRENCH (M4 X 60MM - RBW)	1PC
2	BOLT (M6 X 30MM - RBW)	4PCS
3	LOCK WASHER (M6 X 30MM - RBW)	4PCS
4	FLAT WASHER (M6 X 30MM - RBW)	4PCS
5	WOOD DOWEL (M8 X 30MM)	14PCS
6	LEVELER	8PCS

ASSEMBLY INSTRUCTIONS


STEP 1

Attention! Please remove part B and all hardware from TOP (A), using ALLEN WRENCH (1) and keep for STEP 8 and STEP 9.





STEP 2




STEP 3




ASSEMBLY INSTRUCTIONS


STEP 4



STEP 5




STEP 6




ASSEMBLY INSTRUCTIONS








STEP 8



STEP 9


Attention! Use hardware from STEP 1 for this STEP.



COASTER

ASSEMBLY INSTRUCTIONS

STEP 10




STEP 11 COMPLETE









Note: Dimension tolerance ±5%

COASTERFURNITURE.COM



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

193822 Side Chair

REVISION 0 : 7/14/2025

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM: 193822

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A SEAT AND BACK

B FRONT LEG

C BACK LEG

1PC

2PCS

HARDWARE IDENTIFICATION


1	ALLEN WRENCH (M4 X 60MM - RBW)	1PC
2	LONG BOLT (M6 X 60MM - RBW)	8PCS
3	LOCK WASHER (M6 X 13MM - RBW)	8PCS
4	FLAT WASHER (M6 X 19MM - RBW)	8PCS

ITEM: **193822**


ASSEMBLY INSTRUCTIONS




STEP 1



STEP 2



STEP 3 COMPLETE






COASTERFURNITURE.COM

ITEM: 193822





Note: Dimension tolerance ±5%