

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115391 <u>Dining Table</u>

REVISION 0: 07/30/2025

PAGE 1 OF 4

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION

1PC **TOP UPPER MOUNTING** 2PCS **PLATE** 1PC **LOWER MOUNTING** 2PCS **LEAF** В **PLATE** 2PCS **CROSSBAR** 1PC C **LEG** D **BASE** 1PC

HARDWARE IDENTIFICATION

1	SHORT BOLT (1/4" x 32mm - BLK)		12PCS	5	BIG FLAT WASHER (5/16" x 19 x 1.5mm - BLK)	0	30PCS
2	MEDIUM BOLT (5/16 x 40mm - BLK)		22PCS	6	ALLEN WRENCH (74 x 30 x 4mm - BLK)		1PC
3	LONG BOLT (5/16" x 50mm - BLK)		8PCS	7	SMALL LOCK WASHER (1/4" - BLK)	3	12PCS
4	BIG LOCK WASHER (5/16" - BLK)	· (3)	30PCS	8	SMALL FLAT WASHER (1/4" x 19 x 1.5mm - BLK)		12PCS


ITEM: 115391 **ASSEMBLY INSTRUCTIONS** STEP 1 STEP 2 STEP 3 3.1 (E) 3.2 PAGE 3 OF 5 COASTERFURNITURE.COM




ASSEMBLY INSTRUCTIONS




STEP 6



STEP 7 COMPLETE







Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115392 Side Chair

REVISION 0: 07/30/2025

PAGE 1 OF 4

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.

(74 x 30 x 4mm - BLK)

- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

Α **SEAT AND BACK** 1PC В **FRONT LEG** 2PCS C **BACK LEG** 2PCS HARDWARE IDENTIFICATION **BOLT** 1 8PCS (5/16" x 50mm - BLK) **LOCK WASHER** 8PCS (5/16" - BLK) 3 **FLAT WASHER** 8PCS (5/16" x 19 x 1.5mm - BLK) 4 **ALLEN WRENCH** 1PC




ASSEMBLY INSTRUCTIONS

STEP 3


COMPLETE











Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115393 Side Chair

REVISION 0: 07/30/2025

PAGE 1 OF 4

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


15 MINUTES

PARTS IDENTIFICATION


Α **SEAT AND BACK** 1PC В **FRONT LEG** 2PCS C **BACK LEG** 2PCS HARDWARE IDENTIFICATION **BOLT** 1 8PCS (5/16" x 50mm - BLK) **LOCK WASHER** 8PCS (5/16" - BLK) 3 **FLAT WASHER** 8PCS (5/16" x 19 x 1.5mm - BLK) 4 **ALLEN WRENCH** 1PC (74 x 30 x 4mm - BLK)

ASSEMBLY INSTRUCTIONS





STEP 2





ASSEMBLY INSTRUCTIONS

STEP 3


COMPLETE











Note: Dimension tolerance ±5%