



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



609613PP
Power Recliner

ITEM: **609613PP**

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES


PARTS IDENTIFICATION

A SEAT



1PC

B BACK



1PC

C ADAPTER



1PC

D POWER CABLE




1PC


ITEM: **609613PP**

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2




STEP 3



- ① Type C
- ② USB PORT
- ③ Open recliner
- ④ Close recliner
- ⑤ Open headrest
- ⑥ Close headrest
- ⑦ Home Button



ITEM: **609613PP**



Note: Dimension tolerance $\pm 5\%$