



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

603253PP Dual Power Glider Recliner

ITEM: 603253PP



ASSEMBLY INSTRUCTION


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION

A SEAT BODY



1PC

B ADAPTER



1PC

C BACKREST




1PC

ITEM: 603253PP


ASSEMBLY INSTRUCTION

COASTER
FINE FURNITURE


STEP 1



STEP 3




STEP 2



**BACK VIEW




STEP 4 COMPLETE



ITEM: 603253PP



OPERATING MANUAL

COASTER
FINE FURNITURE



ITEM: 603253PP

COASTER
FINE FURNITURE



Note: Dimension tolerance $\pm 5\%$