

# Assembly Instruction

ITEM NO.: 194H4798LG /BU






STORAGE BENCH




Legs & Hardware are stored in the bench,  
Please take out the legs and hardware for assembly

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


## Component list

No	Drawing	Qty	Description
A		1	<b>BENCH</b>
B		4	<b>WOODEN LEGS 70*70*60MM</b>
C		4	<b>BOLT M8*50mm</b>
D		4	<b>FLAT WASHER M8</b>
E		1	<b>ALLEN KEY M4</b>

## Step #1



## Step #2



## Care Instruction for Boucle Furniture:

In order to maintain the original appearance of your boucle furniture, please follow below simple care procedures.

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage boucle.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight, Re-tighten if necessary



For items use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.