



## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**222527**  
**Writing Desk**

ITEM: 222527

**COASTER**  
FINE FURNITURE

## ASSEMBLY INSTRUCTIONS


### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES


## PART IDENTIFICATION

A DESK TOP




1PC

B LEFT SIDE FRAME



1PC

C RIGHT SIDE FRAME



1PC

D BACK STRETCHER



1PC


## HARDWARE IDENTIFICATION

1	BOLT (5/16 x 50mm - BLK)		8PCS
2	LOCK WASHER (1.6 x 14mm - BLK)		8PCS
3	FLAT WASHER (2 x 19mm - BLK)		8PCS
4	ALLEN WRENCH (M5 x 65mm - BLK)		1PC
5	FLAT HEAD SCREW (8 x 2" - BLK)		2PCS
6	WOOD DOWEL (10 x 40mm - BRW)		4PCS


ITEM: 222527

## ASSEMBLY INSTRUCTIONS

### STEP 1




### STEP 2




**ITEM: 222527**  
**ASSEMBLY INSTRUCTIONS**

**STEP 3**

**COASTER**  
FINE FURNITURE



**STEP 4**




ITEM: 222527



## ASSEMBLY INSTRUCTIONS

### STEP 5

**COASTER**  
FINE FURNITURE




### STEP 6 COMPLETE



ITEM: 222527

**COASTER**  
FINE FURNITURE

Inner Size of Drawer : 17.75"W x 12.75"D x 1.50"H x 0.50"T



Note: Dimension tolerance  $\pm 5\%$