

# ASSEMBLY INSTRUCTIONS


ITEM NO: 194S1006GRY/BEG/BUE/CRC-1  
Accent Chair



Legs and hardware are stored under the seat cushion, please take them out for assembly  
Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.

PART	DRAWING	DESCRIPTION	QTY
A		Seat	1 PC
B		Front Wood Leg 9-1/2"x2"x2"	2 PCS
C		Rear Wood Leg 9-1/2"x2"x2"	2 PCS
D		Seat Cushion	1 PC


## STEP 1:




# ASSEMBLY INSTRUCTIONS

ITEM NO: 194S1006GRY/BEG/BUE/CRC-1  
Accent Chair

## STEP 2:




## STEP 3:



### Care Instruction for Textured Furniture:

In order to maintain the original appearance of your textured furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets.  
Sunlight and/or exposure to heating and air conditioning outlets will fade/damage textured furniture.
  - Vacuum or wipe with a soft cloth to remove dust.
  - Hardware may loosen over time. Periodically check to make sure all connections are tight, Re-tighten if necessary
-  For item use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.