

# Assembly Instruction

ITEM NO.: 194S1029RN/BE/GY-1










## Accent Chair



**Legs & hardware are stored in the bottom of the seat, please take them out for assembly.**


**Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood. Do not tighten bolts until completely assembled.**

### Component list


No	Drawing	Qty	Description
A		1	Chair
B		1	Seat cushion
C		1	Back cushion
D		2	Front Wooden Leg 8.15"*3.23"*3.23"
E		2	Rear Wooden Leg 7.2"*3.23"*3.23"
F		12	Bolts 5/16"*32mm
G		12	Flat Washers Ø19*Ø8*1.5mm
H		12	Lock Washers 5/16"*13*1.5mm
I		1	Allen Wrench M4*70*35mm

Step #1


LEGS AND HARDWARE ARE STORED IN THE BOTTOM OF THE SEAT.



Step #2



### Step #3



## Care Instruction for Chenille Furniture:

In order to maintain the original appearance of your chenille furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage chenille.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight, Re-tighten if necessary



For items use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.