Assembly Instruction

ITEM NO.: 194S9728LGY-1 RECLINING CHAIR




Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


Component list


| No | Drawing | Qty | Description |
|----|---------|-----|-------------|
| Α | | 1 | SEAT |
| В | | 1 | BACK REST |
| С | | 1 | LSF EAR |
| D | | 1 | RSF EAR |

Step #1



Step #2





Care Instruction for Textured microfiber match corduroy furniture: In order to maintain the original appearance of your Textured microfiber match corduroy furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage Textured microfiber match corduroy.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connection are tight, Re-tighten if necessary.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.