

Assembly Instruction

ITEM NO.: 194S1012GRY/TPE-1

Accent Chair




Hardware and Legs are stored in the seat cushion, please take out the legs and hardware for assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


Component list

No	Drawing	Qty	Description
A		1	CHAIR
B		4	WOODEN LEG Ø2"x12"H
C		12	BOLT Ø1/4"X70MM
D		12	FLAT WASHER Ø1/4"
E		12	LOCK WASHER Ø1/4"
F		1	ALLEN KEY 4MM

Step #1



Step #2



Care Instructions for Textured Furniture:

In order to maintain the original appearance of your textured furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage textured furniture.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight, Re-tighten if necessary



For items use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.