
INSTALLATION INSTRUCTIONS



IMPORTANT NOTICE

Workspace Safety

Keep the workspace clear of clutter and ensure it's well-lit. A clean, flat surface is essential.

Read Instructions

Read the entire assembly guide before starting. Skipping steps can compromise safety.

Use Proper Tools

Use the tools provided or recommended. Avoid overtightening screws.

Secure Furniture

Anchor tall or heavy furniture to the wall to prevent tipping. This is crucial in homes with children or pets.

Handle Small Parts

Keep small parts away from children and pets to avoid choking hazards.

Get Help

Don't hesitate to ask for help with heavy or complex pieces.

Inspect Regularly

Periodically check for loose screws or wobbly parts and tighten as needed.

Follow these tips for a safe assembly process.



Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:

- Install tipover restraint provided.
- Place heaviest items in the lowest drawers.
- Do not set TV's or other heavy objects on top of this product, unless the product is specifically designed to accommodate them.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time

Use of tip-over restraints may only reduce, but not eliminate, the risk of tip-over.

This is a permanent label. Do not remove!




ASSEMBLY DIAGRAM (5) 11)



Layout Parts on Soft Surface

Lay out all parts on a soft surface i.e. Rug, Carpet or Packaging Carton.




PARTS LIST


No.	Description	QTY	No.	Description	QTY
1		1	8		2
2		1	9	\Diamond	1
3		1	10		1
4		1	11		1
5	\Diamond	1	12		1
6		1	13		1
7		2			


HARDWEAR LIST


No.	Description	QTY	No.	Description	QTY
Α	OT THE REAL PROPERTY.	29	J		1
В	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	29	K	3x12mm	2
С		29	М		4
D		10	S	S4	1
E	4x38mm	4	W		16
F		4	X		2
G	3.5x12mm	44	Y	O Sana	2
Н		2	Z	<i></i>	2
	4x18mm	4			
					_


YOU MAY NEED(NOT SUPPLIED) 1















13





Hinge Adjustment Guide Three-way adjustable hinge for perfectly aligned doors


Sideways/Gap Adjustment
Turning the screw "2" on the hinges of each door allows you to adjust the door to the left or right by a few millimeters.


Forward/Backward Alignment Loosen screw " 1 " to adjust the door forward or backward.After adjustment,Tighten screw " 1 ".

Vertical Height Adjustment Loosen screw "3" to adjust the door up or down.After adjustment,hold the door panel and tighten screw "3".









We have always been trying to provide the best service and reliable products for every customer. However, accident may happen sometimes, please contact us to resolve any issue before leaving a negative feedback. Many thanks and welcome to our shop again! E-mail: uev_eusupport@163.com	Thank you very much for purchasing from us.
negative feedback. Many thanks and welcome to our shop again!	We have always been trying to provide the best service and reliable products for every customer.
E-mail: uev_eusupport@163.com	
	E-mail: uev_eusupport@163.com