














ASSEMBLY INSTRUCTION


ITEM NO: 194S9557BUE-C1A
CHAIR WITH ONE ARM & STORAGE

NO.	PARTS LIST	QTY	DESCRIPTION	NO.	PARTS LIST	QTY	DESCRIPTION
A		1	Seat Frame	G		4	Allen Bolt ØM8*50
B		1	LSF/RSF Armrest	H		3	Allen Bolt ØM8*35
C		1	Back Rest	I		7	Flat Washer M8*Ø22*1.5mm
D		1	Back Cushion	K		7	Lock Washer M8
E		4	Plastic Leg 65*65*118mm	L		1	Allen Key M5*100*50mm
F		4	Washer	M		2	Clamp 60*40*5mm

STEP 1: Take out LSF/RSF Armrest (**B**), Back rest (**C**) from the bottom.




STEP 2:




ASSEMBLY INSTRUCTION

ITEM NO: 194S9557BUE-C1A
CHAIR WITH ONE ARM & STORAGE

STEP 3:




STEP 4:




ASSEMBLY INSTRUCTION

ITEM NO: 194S9557BUE-C1A
CHAIR WITH ONE ARM & STORAGE

STEP 5:



STEP 6:



CARE INSTRUCTION FOR FABRIC FURNITURE





In order to maintain the original appearance of your fabric furniture, please follow below simple care procedures.

°Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage fabric.


°Wipe gently with a damp soft cloth to remove dust, dirt and any grime build up.

ASSEMBLY INSTRUCTION


ITEM NO: 194S9557BUE-C1A
CHAIR WITH ONE ARM & STORAGE

NO.	PARTS LIST	QTY	DESCRIPTION
A		1	Chair With One Arm & Storage
B		1	Armless Chair With Storage
C		1	Corner Seat With Storage
D		1	Ottoman With Storage

STEP 7:













STEP 8:




ASSEMBLY INSTRUCTION

ITEM NO: 194S9557BUE-AC
ARMLESS CHAIR WITH STORAGE

NO.	PARTS LIST	QTY	DESCRIPTION	NO.	PARTS LIST	QTY	DESCRIPTION
A		1	Seat Frame	F		3	Allen Bolt øM8*35
B		1	Back Rest	G		3	Flat Washer M8*ø22*1.5mm
C		1	Back Cushion	H		3	Lock Washer M8
D		4	Plastic Leg 65*65*118mm	I		1	Allen Key M5*100*50mm
E		4	Washer	K		2	Clamp 60*40*5mm


STEP 1: Take out Back Rest(**B**), Back Cushion(**C**), Plastic leg(**D**), Washer(**E**), Allen Bolt(**F**), Flat Washer(**G**), Lock Washer(**H**), Allen Key(**I**), Clamp(**K**) from the bottom.




ASSEMBLY INSTRUCTION

ITEM NO: 194S9557BUE-AC
ARMLESS CHAIR WITH STORAGE

STEP 2:




STEP 3:




ASSEMBLY INSTRUCTION

ITEM NO: 194S9557BUE-AC
ARMLESS CHAIR WITH STORAGE

STEP 4:



STEP 5:



CARE INSTRUCTION FOR FABRIC FURNITURE





In order to maintain the original appearance of your fabric furniture, please follow below simple care procedures.


°Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage fabric.

°Wipe gently with a damp soft cloth to remove dust, dirt and any grime build up.


ASSEMBLY INSTRUCTION

ITEM NO: 194S9557BUE-AC
ARMLESS CHAIR WITH STORAGE


NO.	PARTS LIST	QTY	DESCRIPTION
A		1	Chair With One Arm & Storage
B		1	Armless Chair With Storage
C		1	Corner Seat With Storage
D		1	Ottoman With Storage



STEP 6:
















STEP 7:




ASSEMBLY INSTRUCTION

ITEM NO: 194S9557BUE-CR
CORNER SEAT WITH STORAGE

NO.	PARTS LIST	QTY	DESCRIPTION	NO.	PARTS LIST	QTY	DESCRIPTION
A		1	Seat Frame	H		4	Washer
B		1	Left Back Rest	I		6	Allen Bolt ØM8*35
C		1	Right Back Rest	K		6	Flat Washer M8*Ø22*1.5mm
D		1	Left Back Cushion	L		6	Lock Washer M8
E		1	Right Back Cushion	M		1	Allen Key M5*100*50mm
F		1	Ear	N		2	Clamp 60*40*5mm
G		4	Plastic Leg 65*65*118mm				


STEP 1: Take out Left Back rest(B), Right Back rest(C), Plastic leg(G), Washer(H), Allen Bolt(I), Flat Washer(K), Lock Washer(L), Allen Key(M), Clamp(N) from the bottom.




ASSEMBLY INSTRUCTION

ITEM NO: 194S9557BUE-CR
CORNER SEAT WITH STORAGE


STEP 2:



STEP 3:




STEP 4:




ASSEMBLY INSTRUCTION

ITEM NO: 194S9557BUE-CR
CORNER SEAT WITH STORAGE

STEP 5:



STEP 6:



CARE INSTRUCTION FOR FABRIC FURNITURE





In order to maintain the original appearance of your fabric furniture, please follow below simple care procedures.


°Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage fabric.

°Wipe gently with a damp soft cloth to remove dust, dirt and any grime build up.


ASSEMBLY INSTRUCTION

ITEM NO: 194S9557BUE-CR
CORNER SEAT WITH STORAGE

NO.	PARTS LIST	QTY	DESCRIPTION
A		1	Chair With One Arm & Storage
B		1	Armless Chair With Storage
C		1	Corner Seat With Storage
D		1	Ottoman With Storage



STEP 7:



STEP 8:

