

ITEM NO: 194S9557BUE-C1A CHAIR WITH ONE ARM & STORAGE

| NO. | PARTS LIST | QTY | DESCRIPTION                | NO.             | PARTS LIST | QTY | DESCRIPTION                 |
|-----|------------|-----|----------------------------|-----------------|------------|-----|-----------------------------|
| А   | ***        | 1   | Seat Frame                 | G               |            | 4   | Allen Bolt<br>ØM8*50        |
| В   |            | 1   | LSF/RSF Armrest            | F/RSF Armrest H |            | 3   | Allen Bolt<br>ØM8*35        |
| С   |            | 1   | Back Rest                  | 1               | 0          | 7   | Flat Washer<br>M8*¢22*1.5mm |
| D   | ++         | 1   | Back Cushion               | К               | 0          | 7   | Lock Washer<br>M8           |
| Е   | <b></b>    | 4   | Plastic Leg<br>65*65*118mm |                 |            | 1   | Allen Key<br>M5*100*50mm    |
| F   |            | 4   | Washer                     | М               |            | 2   | Clamp<br>60*40*5mm          |

**STEP 1:** Take out LSF/RSF Armrest (**B**), Back rest(**C**) from the bottom.




STEP 2:




ITEM NO: 194S9557BUE-C1A CHAIR WITH ONE ARM & STORAGE






STEP 4:




ITEM NO: 194S9557BUE-C1A CHAIR WITH ONE ARM & STORAGE

### STEP 5:



### STEP 6:




#### CARE INSTRUCTION FOR FABRIC FURNITURE

In order to maintain the original appearance of your fabric furniture, please follow below simple care procedures.

<sup>°</sup>Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage fabric.

<sup>°</sup>Wipe gently with a damp soft cloth to remove dust, dirt and any grime build up.


ITEM NO: 194S9557BUE-C1A CHAIR WITH ONE ARM & STORAGE



ITEM NO: 194S9557BUE-AC ARMLESS CHAIR WITH STORAGE


| NO. | PARTS LIST                             | QTY | DESCRIPTION                | NO.         | PARTS LIST | QTY | DESCRIPTION                 |
|-----|--|-----|----------------------------|-------------|------------|-----|-----------------------------|
| А   | XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX | 1   | Seat Frame                 | F           |            | 3   | Allen Bolt<br>ØM8*35        |
| В   |  | 1   | Back Rest                  | Back Rest G |            | 3   | Flat Washer<br>M8*¢22*1.5mm |
| С   | (++)                                   | 1   | Back Cushion               | Н           | 0          | 3   | Lock Washer<br>M8           |
| D   | <b></b>                                | 4   | Plastic Leg<br>65*65*118mm |             |            | 1   | Allen Key<br>M5*100*50mm    |
| Е   | €                                      | 4   | Washer                     | К           |            | 2   | Clamp<br>60*40*5mm          |

STEP 1: Take out Back Rest(B), Back Cushion(C), Plastic leg(D), Washer(E), Allen Bolt(F), Flat Washer(G), Lock Washer(H), Allen Key(I), Clamp(K) from the bottom.




ITEM NO: 194S9557BUE-AC ARMLESS CHAIR WITH STORAGE

### STEP 2:




### STEP 3:




ITEM NO: 194S9557BUE-AC ARMLESS CHAIR WITH STORAGE

#### STEP 4:



### STEP 5:




#### CARE INSTRUCTION FOR FABRIC FURNITURE

In order to maintain the original appearance of your fabric furniture, please follow below simple care procedures.

°Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage fabric.

<sup>°</sup>Wipe gently with a damp soft cloth to remove dust, dirt and any grime build up.


ITEM NO: 194S9557BUE-AC ARMLESS CHAIR WITH STORAGE




ITEM NO: 194S9557BUE-CR CORNER SEAT WITH STORAGE

| NO. | PARTS LIST | QTY | DESCRIPTION                | NO. | PARTS LIST | QTY | DESCRIPTION                 |
|-----|------------|-----|----------------------------|-----|------------|-----|-----------------------------|
| A   | ××××       | 1   | Seat Frame                 | Н   | Н 🍘        |     | Washer                      |
| В   |            | 1   | Left Back Rest             |     |            | 6   | Allen Bolt<br>ØM8*35        |
| С   |            | 1   | Right Back Rest            | К   | 0          | 6   | Flat Washer<br>M8*¢22*1.5mm |
| D   | ++         | 1   | Left Back Cushion          | Г   | 0          | 6   | Lock Washer<br>M8           |
| Е   | ++         | 1   | Right Back Cushion         | М   |            | 1   | Allen Key<br>M5*100*50mm    |
| F   | Ŵ          | 1   | Ear                        | N   |            | 2   | Clamp<br>60*40*5mm          |
| G   | <b></b>    | 4   | Plastic Leg<br>65*65*118mm |     |            |     |                             |

STEP 1: Take out Left Back rest(**B**), Right Back rest(**C**), Plastic leg(G), Washer(H), Allen Bolt(I), Flat Washer(K), Lock Washer(**L**), Allen Key(M), Clamp(N) from the bottom.




ITEM NO: 194S9557BUE-CR CORNER SEAT WITH STORAGE




ITEM NO: 194S9557BUE-CR CORNER SEAT WITH STORAGE

STEP 5:



STEP 6:




#### CARE INSTRUCTION FOR FABRIC FURNITURE

In order to maintain the original appearance of your fabric furniture, please follow below simple care procedures.

°Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage fabric.

°Wipe gently with a damp soft cloth to remove dust, dirt and any grime build up.


ITEM NO: 194S9557BUE-4 OTTOMAN WITH STORAGE



ITEM NO: 194S9557BUE-4 OTTOMAN WITH STORAGE


| NO. | PARTS LIST | QTY | DESCRIPTION                |
|-----|------------|-----|----------------------------|
| Α   | (x x x)    | 1   | Seat Frame                 |
| В   |            | 4   | Plastic Leg<br>65*65*118mm |
| С   |            | 4   | Washer                     |
| D   |            | 2   | Clamp<br>60*40*5mm         |

 $\label{eq:step} \textbf{STEP 1:} \ \ \text{Take out Plastic leg(B), Washer(C), Clamp(D) from the bottom}.$ 




ITEM NO: 194S9557BUE-4 OTTOMAN WITH STORAGE





### STEP 3:



#### CARE INSTRUCTION FOR FABRIC FURNITURE

In order to maintain the original appearance of your fabric furniture, please follow below simple care procedures.

°Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage fabric.

°Wipe gently with a damp soft cloth to remove dust, dirt and any grime build up.

ITEM NO: 194S9557BUE-4 OTTOMAN WITH STORAGE

