
# OKEYSEN COMFORT YOUR LIFE



Assembly Instructions
HKOFOC039



### Assembly Instructions HKOFOC039

#### **INSTALLATION GUIDE**

ONE PERSON ASSEMBLY: 15 MINUTES (APPROXIMATE)
TOOLS REQUIRED:ALLEN WRENCH (PROVIDED)

#### **BEFORE ASSEMBLY**

- 1. Remove all packaging materials, staples and packing straps from the carton.
- 2. Confirm with Parts Checklist in Page 3.

#### **ATTENTION**

- 1. Leave sufficient room for assembly.
- 2. Do not assemble on the ground that may hurt the product.
- 3. Do not over-tighten any fittings as it may cause damage.
- 4. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
- **5.** Do not sit or stand on it before the assembly is complete.

#### **DAILY MAINTENANCE**

- 1. Recommended for indoor use only.
- 2. Wipe with a soft, dry cloth. Keep away from abrasives and household cleaners.
- **3.** Check all the fittings periodically and re-tighten if necessary. Do not use the product if any part is damaged or broken.

#### **Okeysen Office Desk Chair Limited Warranty**

Okeysen office desk chairs are warranted from the date of purchase against failure due to material and workmanship as follows:

- 1 YEAR on all unmovable metal parts;
- 1 YEAR on upholstered PU leather and foam;
- 1 YEAR on component parts including control mechanisms, gas cylinder, wood, plastic parts, base and casters.


To make a warranty claim, please contact Okeysen with model number, purchase proof and problem descriptions.


Problem verified, Okeysen will:


- a) Send a replacement.
- b) Send a new product if necessary, customer need to return the original one to our warehouse. Return freight will be undertaken by Okeysen.


#### **RETURN POLICY**

30 days return policy after receiving is provided. Okeysen offers prepaid return labels for product quality issues.












**Step 3**: Fix Brackets **Gx2** with the Chair Back **F** with Screws **Hx2** and finish with Allen Wrench **K**.



**Step 4**: Attach Seat **E** with Assembled Seat Back via Screws **Ix2** and Screws **Jx2** as shown in the picture and finish with Allen Wrench **K**.








## Parts Missing?

We are working on delivering you a perfect product, but sometimes the parts may still be damaged or lost in transit.

If any parts are damaged or lost, please contact us immediately, we will give you a perfect solution.



CONTACT INFO: Support@Okeysen-Global.com