


ASSEMBLY INSTRUCTION

ITEM: N715P355018


DINING BENCH









IMPORTANT NOTE :


- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ② BEFORE YOU BEGIN , KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- ③ DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE BENCH IS FULLY SET-UP

Detail view







Part List	Hardware List
A 	1  Ø1/4" x 60mm
	Bolt (8pcs)
	2  Ø1/4" x 13mm x 1.5mm
	Spring Washer (8pcs)
Seat bench (1pc)	3  Ø1/4" x 19mm x 1.5mm
B 	Flat Washer (8pcs)
	4  4 x 58mm
Bench Legs (4pcs)	Allen Key (1pc)

Step 1



Completed

1	Ø1/4"x60		4PCS	3	Ø1/4"x19x1.5		4PCS
2	Ø1/4"x13x1.5		4PCS	4	4x58		1PC