


ASSEMBLY INSTRUCTION

ITEM: N715P362475


DINING CHAIR



IMPORTANT NOTE :

- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ② BEFORE YOU BEGIN , KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- ③ DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CHAIR IS FULLY SET-UP


Detail view



Part List For One Chair


Hardware List For One Chair

A




Backrest (1pc)

B




Seat Cushion (1pc)

C




Left Front Legs (1pc)

D




Right Front Legs (1pc)

E




Left Stretcher (1pc)

F



Right Stretcher (1pc)

G



Center Stretcher (1pc)

1



Ø1/4" x 75mm

Bolt (4pcs)

2



Ø1/4" x 60mm

Bolt (4pcs)

3



Ø1/4" x 35mm

Bolt (2pcs)

4



Ø1/4" x 13mm x 1.5mm

Spring Washer (10pcs)

5



Ø1/4" x 19mm x 1.5mm

Flat Washer (10pcs)

6



4 x 58mm

Allen Key (1pc)


7




Ø4" x 38mm





SCREW (6pcs)

ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)








Step 1




3	Ø1/4"x35		2PCS	5	Ø1/4"x19x1.5		2PCS
4	Ø1/4"x13x1.5		2PCS	6	4x58		1PC





Step 2




1	Ø1/4"x75		4PCS	5	Ø1/4"x19x1.5		4PCS
4	Ø1/4"x13x1.5		4PCS	6	4x58		1PC

Step 3




2	Ø1/4"x60		4PCS	5	Ø1/4"x19x1.5		4PCS
4	Ø1/4"x13x1.5		4PCS	6	4x58		1PC

Step 4



Completed

7	Ø4x38		6PCS
----------	-------	---	------