ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance.

Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched.

Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

4. Required two man lift

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver & RubberMallet (not provider).

PART LIST				
ITEM	DESCRIPTION	BOX	QTY	
Α	HEADBOARD	1	1 PC	
В	FOOTBOARD	2	1 PC	
С	SIDE RAIL	2	2 PCS	
D	CENTER RAIL	2	1 PC	
E	CENTER RAIL LEG	2	3 PCS	
F	FOOTBOARD WOOD (L/R)	3	2 PCS	
G	HEADBOARD WOOD (L/R)	3	2 PCS	
Н	FOOTBOARD TOP WOOD	3	1 PC	
I	HEADBOARD TOP WOOD	3	1 PC	
J	SIDE RAIL TOP WOOD	3	2 PCS	
K	BED SLAT	2	1 SET	

HARDWARE LIST				
ITEM	DESCRIPTION		QTY	
1	JCBC BOLT M6 x 40mm	(((((((((((((((((((((((((((((((((((((4 PCS	
2	M6 FLAT WASHER	0	4 PCS	
3	M8 FLAT WASHER	0	4 PCS	
4	WOOD DOWEL M8 x 30mm		4 PCS	
5	WOOD SCREW M4 x 32mm	~~~~~ €	9 PCS	
6	M8 HEX NUT		4 PCS	
7	SPANNER (13mm)	Y	1 PC	
8	M4 ALLEN KEY (BALL SHAPE)		1 PC	
9	WOOD SCREW M4 x 20mm	40000	2 PCS	









