





N725P331357
ASSEMBLY INSTRUCTIONS
STORAGE CABINET




Thank you for purchasing this quality product. Be sure to check all parts material carefully for small parts which may have come loose inside carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present, "DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"

- * Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe!!!
- * Please assemble on a clean soft surface to avoid damage.



Tools Required



(Not Included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY
VEUILLEZ LIRE LES INSTRUCTIONS AVANT DE COMMENCER L'ASSEMBLAGE

Before Installation

Important - Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

. We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.







. Please do not over tighten screws or bolts until the assembly is completed.

. Keep children and animal away from the work area, small parts could choke if swallowed.




. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

























Cam Lock Assembly Instructions

	Insert Cam Bolt into hole as shown in diagram A.
	Make sure not to insert the Cam Bolt. Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.
	Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.
	Connect the panels together.
	ARROW SIGN Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
	To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>











PRODUCT DETAILS DÉTAILS DU PRODUIT













PART LIST / LISTE DES PIÈCES


①	ROOF BOARD		1 PC	⑬	ADJUSTABLE SHELVES BELOW		1 PC
②	TOP LEFT BOARD		1 PC	⑭	LOWER CENTER BOARD		1 PC
③	TOP RIGHT BOARD		1 PC	⑮	BOTTOM BOARD		1 PC
④	ADJUSTABLE SHELVES ABOVE		1 PC	⑯	FRONT BAR FOOT BASE		1 PC
⑤	FIXED SHELF		1 PC	⑰	MIDDLE LEG		1 PC
⑥	TOP BOTTOM BOARD		1 PC	⑱	BOTTOM BACK BOARD		2 PCS
⑦	TOP BACK BOARD		2 PCS	⑲	BOTTOM RIGHT DOOR		1 PC
⑧	PLASTIC SUPPORT		1 PC	⑳	DRAWER FRONT		3 PCS
⑨	TOP LEFT DOOR		1 PC	㉑	DRAWER SIDE LEFT		3 PCS
⑩	TOP RIGHT DOOR		1 PC	㉒	DRAWER SIDE RIGHT		3 PCS
⑪	LOWER LEFT BOARD		1 PC	㉓	DRAWER BACK		3 PCS
⑫	LOWER RIGHT BOARD		1 PC	㉔	DRAWER BOTTOM		3 PCS

HARDWARE LIST/LISTE DU MATÉRIEL



Ⓐ	<u>CR</u>		3 PCS
	<u>DR</u>		3 PCS
	<u>CL</u>		3 PCS
	<u>DL</u>		3 PCS
Ⓑ	Ø3.5*12MM		72 PCS
Ⓒ	Ø8*30MM		26 PCS
Ⓓ	Ø5*35MM		45 PCS
Ⓔ	Ø15*10MM		45 PCS
Ⓕ	M6*60MM		3 SETS
Ⓖ	M4*15MM		6 SETS



Ⓜ	L15MM		8 PCS
Ⓜ	HINGLE		6 PCS
Ⓜ	Ø3.5*12MM		8 PCS
Ⓜ	M4*50MM		12 SETS
Ⓜ	L 4*58MM		1 PC
Ⓜ	  		2 SETS
			


ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)
OUTILS D'ASSEMBLAGE REQUIS (NON INCLUS)







STEP 1







Ⓒ	Ø8*30MM		2 PCS
Ⓓ	Ø5*35MM		2 PCS

Ⓔ	Ø15*10MM		2 PCS
---	----------	--	-------


STEP 2







Ⓐ	CR L300MM		3 PCS
Ⓑ	Ø3.5*12MM		18 PCS


Ⓐ	CL L300MM		3 PCS
Ⓓ	Ø5*35MM		4 PCS



STEP 3




Ⓒ	Ø8*30MM		2 PCS	Ⓕ	M6*60MM		3 SETS
Ⓓ	Ø5*35MM		4 PCS	Ⓖ	L 4*58MM		1 PC

STEP 4





Ⓒ	Ø8*30MM		4 PCS	Ⓔ	Ø15*10MM		8 PCS
---	---------	---	-------	---	----------	---	-------

STEP 5




Ⓒ	Ø8*30MM		6 PCS
---	---------	---	-------



STEP 6




Ⓓ	Ø5*35MM		4 PCS
---	---------	---	-------

STEP 7




Ⓒ	Ø8*30MM		4 PCS	Ⓔ	Ø15*10MM		4 PCS
---	---------	---	-------	---	----------	---	-------

STEP 8




Ⓓ	Ø5*35MM		10 PCS
---	---------	---	--------

STEP 9




Ⓒ	Ø8*30MM		4 PCS	Ⓔ	Ø15*10MM		4 PCS
---	---------	--	-------	---	----------	--	-------

STEP 10




STEP 11





Ⓒ	Ø8*30MM		4 PCS	Ⓔ	Ø15*10MM		6 PCS
---	---------	--	-------	---	----------	--	-------


STEP 12





Ⓓ	Ø5*35MM		9 PCS
---	---------	--	-------




STEP 13




E	Ø15*10MM		9 PCS
---	----------	---	-------

STEP 14




	Ø3.5*12MM		8 PCS		L15MM	 8 PCS
--	-----------	---	-------	---	-------	---


STEP 15







Ⓓ	Ø5*35MM		12 PCS
---	---------	---	--------

Ⓚ	M4*50MM		12 SETS
---	---------	---	---------


STEP 16



Ⓐ	<u>DR</u>		3 PCS
	<u>DL</u>		3 PCS


Ⓑ	Ø3.5*12MM		18 PCS
Ⓔ	Ø15*10MM		12 PCS

STEP 17





Ⓒ	M4*15MM		3 SETS
---	---------	--	--------




STEP 18






Ⓑ	Ø3.5*12MM		12 PCS	Ⓘ	HINGLE		6 PCS
---	-----------	--	--------	---	--------	--	-------









STEP 20




Ⓑ	Ø3.5*12MM 	8 PCS
Ⓒ	M4*15MM 	1 SETS
Ⓘ	HINGLE 	2 PCS

STEP 21




Ⓑ	Ø3.5*12MM		16 PCS
Ⓒ	M4*15MM		2 SETS
Ⓘ	HINGLE		4 PCS

STEP 22



HINGE ADJUSTMENTS




1 Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




2 4 Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



3 Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

