
ASSEMBLY INSTRUCTION



AX6PCS	BX6PCS	CX6PCS	DX8PCS	EX1PCS	FX1PCS
	Sa)		(4)		
6x40mm	Ø10x10mm	Ø6x25mm	6x20mm		4x10mm
GX1PCS	HX1PCS	IX6PCS	JX6PCS		
4x30mm	6x30mm				

