


ASSEMBLY INSTRUCTIONS






ITEM NO. FB3061CHY2-TBE












ASSEMBLY TIPS:


1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Part List


NO.	DIAGRAM	PART NAME	Q'ty
#1		Table Top	1 pc
#2		Table Legs	4 pcs
#3		Bench Seat Cushion	1 pc
#4		Bench Seat Frame	1 pc
#5		Bench legs	4 pcs

Hardware List


NO.	DIAGRAM	PART NAME	Q'ty
#A		Bolt 5/16" x 2-1/4"	8 pcs
#B		Spring washer Ø5/16"	8 pcs
#C		Flat washer Ø5/16"	8 pcs
#D		Allen key M5	1 pc
#E		Bolt 5/16" x 2-1/4"	8 pcs
#F		Spring washer Ø5/16"	8 pcs
#G		Flat washer Ø5/16"	8 pcs
#H		Screw #4 x 15mm	10 pcs
#I		Allen key M5	1 pc



STEP 1




STEP 2




Do not tighten screws until completely assembled.

STEP 3



STEP 4



Tighten all screws until completely assembled.