



your global source for unique lighting + home decor

ASSEMBLY INSTRUCTION



CAUTION - Refer to the wattage caution label located near the lamp holder for maximum wattage - do not exceed the maximum wattage.



WARNING - Do not attempt to replace the bulb(s) while the lamp is plugged into a wall receptacle

CARE INSTRUCTIONS - Use only a soft cloth; do not use any chemicals or abrasive cleaners.

IMPORTANT SAFETY INSTRUCTIONS

1. Attach the (C Crossbar) to the outlet box by using two (D Crossbar screw).
 2. Pull out the outlet wires and housing grounding wire from the outlet box. Make wire connections using the wire (B nuts):

--WHITE wire with WHITE-NEUTRAL

--BLACK wire with BLACK-LIVE

--Attached the fixture grounding wire to mounting bracket with (A Ground screw). Carefully tuck the wires back into the outlet box.
 3. Secure the canopy to the (C Crossbar) with (E Canopy screw).
 4. Attached the (F Glass shade) to the lamp holder, put the (G Rubber pad) on then secure it with socket ring(H).
- Important Note: Socket ring is located on the socket.***
5. Install the (I bulb) (not included).

E26 Type A.40W X 1 (Not included)

E26 CFL 13W X 1 (Not included)



MADE IN CHINA

riverofgoods.com

