
# Assembly Instruction

**Swivel Dining Chair** 



## Thank you for choosing our product.

We are committed to delivering exceptional customer service to ensure your satisfaction.

#### **Parts Confirmation:**

- Upon unpacking, verify that all parts listed in the manual are present.
- If any parts are missing or incorrect, please notify us immediately. We will promptly arrange replacements, or other solutions to ensure the issue is resolved.

### **Assembly Guidance:**

- Carefully review the instruction manual before assembly.
- The manual has detailed steps, but it might not cover all situations. If you need help or have questions, contact us and we'll respond quickly.


## **Shipping Note**


 If you purchased multiple packs, kindly note that the items in your order might come in separate packages. We appreciate your patience during delivery.

## Parts List

Number	Name	Part	Qty
1	Seat Back		X1PC
2	Wood Leg		X1PC
3	Wood Leg		X1PC
4	Swivel Gear		X1PC

Number	Hardware	Part	Qty
Α	M6x45mm		X1+1EXT
В	M6x16mm		X4+1EXT
С	M6x13mm	<u> </u>	X8+1EXT
D	Washer		X1+1EXT
E	Washer		X1PC
F	Felt pad		X4+1EXT
G	Metal Plate		X1PC





#### **Safety Guidelines**

- Periodically inspect and tighten bolts to prevent loosening during use.
- Ensure all hardware remains securely fastened before using.
- Do not allow children to climb or jump on the stool.

#### **Care Instructions**

- Avoid placing hot items, direct sunlight, or harsh chemicals on the furniture
- Wipe dust with a soft, clean, lint-free cloth.
- Use adjustable foot levelers on each leg to stabilize the chair on uneven floors.
- Note: Indoor Use Only: Do not place the furniture outdoors or in damp environments.

#### Thank you for your purchase