

# Assembly Instructions


**Caution : You must read this before you proceed**

## Care & Maintenance

- Ø  ● Not for commercial use. For residential use only.
  
- ✓  ● Furniture may scratch floors. We recommend using furniture pads to protect your floors.
  
- Ø  ● Do not put hot items directly on furniture surface.
  
- Ø  ● Do not clean furniture with harsh cleansers or polish.
  
- Ø  ● Do not place furniture under direct sunlight.
  
- Ø  ● Do not place furniture near heating or cooling vents.
  
- Ø  ● Do not write on furniture without a padded barrier to protect the surface.
  
- Ø  ● Do not place furniture outside . For indoor use only.
  
- Ø  ● Stains may be removed with mild soap solution and damp cloth.
  
- Ø  ● Children should not climb or jump on the furniture.
  
- ✓  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in carton for hardware packs and legs.

## Dining Chair



### Parts List


Label	Picture	Description	QTY
A		Back	1
B		Seat	1
C		Back Connection Rod	1
D		Short Connection Rod	1
E		Long Connection Rod	1
F		Left Arm	1
G		Right Arm	1

### Hardware

Label	Picture	Description	QTY
①		Bolt (M6x8mm)	13
②		Bolt (M6x18mm)	8
③		Washer(6*18*1.5mm)	8
④		Allen Wrench (5mm)	1
⑤		Leveller	1

# Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-




- Save all packaging until finished-

# Assembly Steps



This Dining Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Dining Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarize yourself with the parts and steps before assembly.


## Step1



Attach the Back Connection Rod (C), Short Connection Rod (D) and Long Connection Rod (E) to Left Leg (F) and Right Leg (G) using the Bolt (①) with Allen Wrench (④) as shown above.

**Do not fully tighten the Bolts.**


## Step2



Attach the Back (A) to Seat (B) using the Washer (③) and Bolt (②) with Allen Wrench (④) as shown above.

**Do not fully tighten the Bolts.**


## Step 3



Attach the Seat (B) to the assembled left frame using the Washer (③) and Bolt (②) with Allen Wrench (④) as shown above.


**Inspect the assembly and make sure all parts are adequately connected.  
Fully Tighten all the Bolts.**

## Step 4



Stand the Chair up carefully.  
Place the Chair on a LEVEL SURFACE to check for wobbling.  
Adjust the levelers on the legs to ensure Chair stability.

## Step 7



Your Chair is ready for use.  
The Chair can only be used on a flat, level surface.