


ASSEMBLY INSTRUCTIONS


ITEM NO. FB3051CST-PC-4PK



ASSEMBLY TIPS:


1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

PARTS LIST


NO.	DIAGRAM	PART NAME	Q'Ty
1		CHAIR BACK	1PC x4
2		CUSHION SEAT	1PC x4
3		LEG (LEFT /RIGHT)	2PCSx4
4		FRONT STRETCHER	1PC x4
5		STRETCHERS (LEFT/ RIGHT)	2PCSx4

HARDWARE LIST


NO.	DIAGRAM	PART NAME	Q'Ty
A		BOLT Ø1/4" x 1-1/2"	2PCS x4
B		BOLT Ø1/4" x 2-3/8"	4PCS x4
C		BOLT Ø1/4" x 3"	4PCS x4
D		LOCK WASHER Ø1/4"	10PCS x4
E		FLAT WASHER Ø1/4" x 19mm	10PCS x4
F		ALLEN KEY 4mm	1PC x4
H		SCREW #4 x 45mm	6PCS x4



STEP 1




STEP 2




Do not tighten screws until completely assembled.

STEP 3



STEP 4



Tighten all screws until completely assembled.