


ASSEMBLY INSTRUCTIONS

HYBC-004-G


HYBC-004-B

HYBC-004-W




Notice:


1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, please contact our customer service.
4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.



Recommended installers:2



Put a carpet on the floor
before unpacking



Estimate installation time:
30minutes

ASSEMBLY INSTRUCTIONS

PART LIST

Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
(A)		X1	(I)		X1
(B)		X1	(J)		X1
(C)		X1	(K)		X1
(D)		X1	(L)		X1
(E)		X1	(M)		X1
(F)		X1	(N)		X1
(G)		X1	(O)		X1
(H)		X1	(P)		X1





ASSEMBLY INSTRUCTIONS

PART LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
Q		X1	T		X1
R		X1	U		X1
S		X2	V		X1
			W		X1

ASSEMBLY INSTRUCTIONS

HARDWARE LIST




Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
1		X9 $\varnothing 8*30\text{mm}$	7		X2
2		X30+3	8	 $\varnothing 3*14\text{mm}$	X24+2
3		X30+3	9		X4
4		X4 $\varnothing 3.5*50\text{mm}$	10		X6
5		X18+1 $\varnothing 3.5*30\text{mm}$	11	 $\varnothing 5*3/4"$	X6
6		X2	12		X1
			13		X1

ASSEMBLY INSTRUCTIONS





ASSEMBLY INSTRUCTIONS

1





ASSEMBLY INSTRUCTIONS

2





ASSEMBLY INSTRUCTIONS

3






ASSEMBLY INSTRUCTIONS

4





ASSEMBLY INSTRUCTIONS

5





ASSEMBLY INSTRUCTIONS

6




ASSEMBLY INSTRUCTIONS

7




ASSEMBLY INSTRUCTIONS


8



①



②



③

Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.

Adjustment range: 4mm

Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm

Up-Down Direction Adjustment:


Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm

ASSEMBLY INSTRUCTIONS


9

Common Door Panel Issues:




Door panel is not straight


Adjust the door hinges




Finished




The gap between door panels is too large




Adjust the door hinges




Finished




The door panels are not coplanar



Adjust the door hinges





Finished



The two door panels are not at the same height



ASSEMBLY INSTRUCTIONS

10




ASSEMBLY INSTRUCTIONS

11




ASSEMBLY INSTRUCTIONS

12



ASSEMBLY INSTRUCTIONS

13



13 1PCS

