


ASSEMBLY INSTRUCTIONS


HYBC-005-G

HYBC-005-W




Notice:


1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, please contact our customer service.
4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.



Recommended installers:2



Put a carpet on the floor
before unpacking



Estimate installation time:
30minutes

ASSEMBLY INSTRUCTIONS

PART LIST

Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
(A)		X1	(I)		X1
(B)		X1	(J)		X1
(C)		X1	(K)		X1
(D)		X1	(L)		X1
(E)		X1	(M)		X1
(F)		X1	(N)		X1
(G)		X1	(O)		X1
(H)		X1	(P)		X1








ASSEMBLY INSTRUCTIONS

PART LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
Q		X1	V		X1
R		X1	W		X1
S		X1	X		X1
T		X1	Y		X1
U		X2	Z		X1
			ZZ		X4

ASSEMBLY INSTRUCTIONS

HARDWARE LIST



Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
1		X15+1	10		X2
2		X29+2	11		X4
3		X29+2	12		X5
4		X16+1	13		X2
5		X18+1	14		X9
6		X4	15		X4
7		X2	16		X4
8		X36+3	17		X4
9		X1	18		X1

ASSEMBLY INSTRUCTIONS





ASSEMBLY INSTRUCTIONS

1





ASSEMBLY INSTRUCTIONS

2





ASSEMBLY INSTRUCTIONS

3





ASSEMBLY INSTRUCTIONS

4





ASSEMBLY INSTRUCTIONS

5




ASSEMBLY INSTRUCTIONS

6



ASSEMBLY INSTRUCTIONS


7




③ 6PCS



Ø3.5*30mm
⑤ 2PCS






① 4PCS





ASSEMBLY INSTRUCTIONS

8



ASSEMBLY INSTRUCTIONS

9



ASSEMBLY INSTRUCTIONS





10



⑧ 24PCS




⑪ 4PCS




ASSEMBLY INSTRUCTIONS


11



1



2



3

Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.

Adjustment range: 4mm

Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm

Up-Down Direction Adjustment:


Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm

ASSEMBLY INSTRUCTIONS


12

Common Door Panel Issues:




Door panel is not straight


Adjust the door hinges




Finished




The gap between door panels is too large




Adjust the door hinges




Finished




The door panels are not coplanar



Adjust the door hinges






Finished



The two door panels are not at the same height



ASSEMBLY INSTRUCTIONS

13





ASSEMBLY INSTRUCTIONS

14





ASSEMBLY INSTRUCTIONS

15




ASSEMBLY INSTRUCTIONS

16



ASSEMBLY INSTRUCTIONS

17



ASSEMBLY INSTRUCTIONS

18

