


# Assembly Instruction

Dining chair



# Thank you for choosing our product.

We are committed to delivering exceptional customer service to ensure your satisfaction.

## Parts Confirmation:

- Upon unpacking, verify that all parts listed in the manual are present.
- If any parts are missing or incorrect, please notify us immediately. We will promptly arrange replacements, or other solutions to ensure the issue is resolved.

## Assembly Guidance:


- Carefully review the instruction manual before assembly.
- The manual has detailed steps, but it might not cover all situations. If you need help or have questions, contact us and we'll respond quickly.


## Shipping Note

- If you purchased multiple packs, kindly note that the items in your order might come in separate packages. We appreciate your patience during delivery.

# Parts List

Number	Name	Part	Qty
1	Seat		X1PC
2	Front leg		X2PC
3	Rear leg		X2PC


Number	Hardware	Part	Qty
D	M6*40mm		X16+1EXT
E	Flat washers		X16+1EXT
F	Spring washers		X16+1EXT
G	Foot levelers		X4+1EXT
H	Allen Wrench		X1PC

**01**

Finally tighten all screws to a depth of 100%.

**02**

Assembly complete



**Note:**

Each leg has an adjustable foot leveler to help level your chair. Rotate it to ensure the chair is flat on the floor !

## Safety Guidelines

- ⚙️ Periodically inspect and tighten bolts to prevent loosening during use.
- 🌐 Ensure all hardware remains securely fastened before using.
- 🏃 Do not allow children to climb or jump on the stool.

## Care Instructions

- 🔥 Avoid placing hot items, direct sunlight, or harsh chemicals on the furniture
- 拭 ➔ Wipe dust with a soft, clean, lint-free cloth.
- 🔧 Use adjustable foot levelers on each leg to stabilize the chair on uneven floors.
- ⚠️ Note: Indoor Use Only: Do not place the furniture outdoors or in damp environments.

**Thank you for your purchase**