


# TV Stand

Assembly Instructions - Please keep for future reference



## Dimensions

Width- 102.36inch

Depth- 15.75inch

Height-79.6inch



## WARNING



This product is NOT a Clothing Storage Unit (CSU).  
DO NOT use it for clothing storage.  
Improper use may cause furniture tipover.

**Important – Please read these instructions fully before starting assembly**



# Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

## WARNING

**In order to help prevent overturning – please follow these instructions**











To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)  
Do not allow children to climb or hang on the furniture  
Do not open more than one drawer at a time  
Do not place heavy items in the top drawers  
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


# Components - Fittings

Please check you have all the panels listed below



Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

			
<b>A</b> Cam Bolt x 170+2	<b>B</b> 6*30mm Dowel x 144+2	<b>C</b> Cam lock x 170+2	<b>D</b> Slide x 12
			
<b>E</b> 3*12mm Screw x 48+2	<b>F</b> F1 F2 6*25mm Screw x 4set	<b>G</b> 4*40mm Screw x 42+2	<b>H</b> 3.5*14mm Hinge x 8set
			
<b>I</b> 4*10mm Handle x 6set	<b>J</b> J1 J2 x4	<b>K</b> Perfect fit x 100	<b>L</b> Allen key x 2
			
<b>M</b> x 2set	<b>N</b> 4*30mm Screw x 36+2	<b>O</b> Shelf support pin x 8	<b>P</b> 4*18mm Handle x 4set
			
<b>Q</b> x 4set	<b>R</b> x 16set	<b>S</b> S1 S2 S3 S4 x 2set	<b>T</b> T1 T2 6*20mm Screw x 4set

**Tools required** Not Included



Phillips screwdriver  
(medium & large)




# Using Camlocks

## Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.  
NE PAS SERRER EXCESSIVEMENT.



## Step 2

Push the male camlock into the entry hole.

2




## Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




## Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.

The joint is now secure.

4




# Assembly Instructions



# PART LIST

This product comes in 3 box.


N721P415873




# PART LIST

This product comes in 3 box.

N721P415874




# PART LIST




This product comes in 3 box.

N721P415875





# Assembly Instructions

## Step 1




## Step 2




# Assembly Instructions

## Step 3




Cam Bolt x 24

## Step 4



(A)




Cam Bolt x 16

(C)



Cam lock x 12


(B)




6\*30mm Dowel x 9

# Assembly Instructions

## Step 5




## Step 6






# Assembly Instructions


## Step 7



## Step 8




6\*30mm Dowel x 8




Cam lock x 16

# Assembly Instructions

## Step 9




## Step 10




# Assembly Instructions

## Step 11






## Step 12





# Assembly Instructions

## Step 13




# Assembly Instructions

## Step 14





Cam Bolt x 4

## Step 15



6\*30mm Dowel x 4

## Step 16




6\*30mm Dowel x 12




4\*30mm Screw x 12

# Assembly Instructions

## Step 17




## Step 18





# Assembly Instructions

## Step 19




## Step 20




# Assembly Instructions

## Step 21




## Step 22




# Assembly Instructions

## Step 23




## Step 24




# Assembly Instructions

## Step 25




## Step 26





# Assembly Instructions

## Step 27




## Step 28




# Assembly Instructions

## Step 29



step1




step2



step3




## Step 30




# Assembly Instructions

## Step 31





## Step 32





# Assembly Instructions

Step 33



# Assembly Instructions



Step 34



# Assembly Instructions


Step 35

x2




# Assembly Instructions


## Step 36




If the door can't close, please adjust the hinges as below.



This is used to adjust the door panel in the up and down direction.




This is used to adjust the door panel in the left and right direction.



This is used to adjust the door panel in the front and rear.





# Assembly Instructions

Step 37








# Assembly Instructions

## Step 38




## Step 39



# Assembly Instructions

## Step 40






# Assembly Instructions

Step 41

## OPTIONS 1





There is 2 ways of installation.



# Assembly Instructions

## Step 41

### OPTIONS 2



# Assembly Instructions

Finish

