


Kitchen Island Cart

Assembly Instructions - Please keep for future reference

N707P404588 / N707P404589



Important - Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

WARNING

In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-



















Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Components - Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases, more fittings may be supplied than required.


HARDWARE BOX INSIDE BOX 2

1	QTY: 36	2	QTY: 36	3	QTY: 28
					
CAM BOLT		CAM LOCK		WOOD DOWEL	$\varnothing 6*25mm$
4	QTY: 6	5	QTY: 6	6	QTY: 36
					
BALL BEARING GLIDE		BALL BEARING GLIDE		FLAT HEAD SCREW	$\varnothing 6*12mm$
7	QTY: 6	8	QTY: 6	9	QTY: 6
					
BOLT	$1/4''*32mm$	SPRING WASHER		FLAT WASHER	
10	QTY: 12	11	QTY: 7	12	QTY: 14
					
FLAT HEAD SCREW	$\varnothing 6*25mm$	HANDLE		BOLT	$\varnothing 8*12mm$
13	QTY: 8	14	QTY: 90	15	QTY: 7
					
HINGES		FLAT HEAD SCREW	$\varnothing 7*15mm$	HINGES	
17	QTY: 8	18	QTY: 4	19	QTY: 6
					
ROUND HEAD SCREW	$\varnothing 7*15mm$	CASTER		FLAT HEAD SCREW	$\varnothing 8*25mm$
21	QTY: 1	22	QTY: 2	23	QTY: 16
					
ALLEN KEY		SPRING BALL LATCH		BOLT	$\varnothing 1/4*12mm$

Using Camlocks


Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.




Slides Must Be Separated Before Assembly.
After Separated, Set Aside Until Needed for Assembly.

Las diapositivas deben separarse antes del montaje.
Después de la separación, déjelo a un lado hasta que sea necesario.

Les glissières doivent être séparées avant l'assemblage.
Après la séparation, mettez de côté jusqu'au moment de l'assemblage.

Pay attention when connecting !
The sliding module must be at the front end.

STEP 1 : Extend Slide
Extender la diapositiva



Mount Montaje la montura


Lever Elevar Levier

STEP 2: Push Lever UP
Empujar hacia arriba
Lever le levier



**Push lever for the left of drawer ,
press the lever for the right of drawer.**

4




5



STEP 3: Remove Runner
Quitar el corredor
Enever le coureur

Assembly Instructions

Tool required


















Phillips screw driver
(medium & large)







Assembly Instructions

BOX 1 : N707P404588

C _L 	C _R 	F 
LEFT FRAME QTY: 1	RIGHT FRAME QTY: 1	FRONT PANEL - LEFT QTY: 1
G 	H 	I 
FRONT PANEL - RIGHT QTY: 1	FRONT PANEL - MIDDLE QTY: 1	BRACKET - LEFT QTY: 1
J 	K 	L 
BRACKET - RIGHT QTY: 1	BRACKET - LEFT QTY: 1	BRACKET - RIGHT QTY: 1
M 	P 	Q 
BRACKET BOTTOM QTY: 1	MIDDLE SHELF QTY: 1	LEFT/RIGHT SHELF QTY: 2
S 	T 	V 
DRAWER FRONT QTY: 1	DRAWER BACK QTY: 1	DRAWER FRONT QTY: 2














Assembly Instructions

BOX 1 : N707P404588

Y_L 	Y_R 	AA 
DRAWER LEFT BB 	QTY: 3 DRAWER RIGHT QTY: 3	EXTENDED SUPPORT QTY: 1
EXTENDED SUPPORT QTY: 1		



Assembly Instructions

BOX 2 : N707P404589

A	B	DL
		
TOP PANEL QTY: 1	EXTENDED TOP PANEL QTY: 1	CENTER PANEL - LEFT QTY: 1
DR	E	N
		
CENTER PANEL - RIGHT QTY: 1	BOTTOM PANEL QTY: 1	PULL BAR QTY: 4
O	RL	RR
		
BACK PANEL QTY: 1	LEFT DOOR QTY: 2	RIGHT DOOR QTY: 2
U	W	X
		
DRAWER BOTTOM QTY: 1	DRAWER BACK QTY: 2	DRAWER BOTTOM QTY: 2
Z		
		
DOOR STOP QTY: 3		

Assembly Instructions


STEP 1



1		2PCS
4		2PCS
6		6PCS


Assembly Instructions

STEP 2



1		2PCS
4		2PCS
6		6PCS


STEP 3



1		2PCS
4		2PCS
6		6PCS


Assembly Instructions

STEP 4




Assembly Instructions

STEP 5




STEP 6




Assembly Instructions

STEP 7




STEP 8




Assembly Instructions


STEP 9






STEP 10



STEP 11




STEP 12




X2

Assembly Instructions

STEP 13




STEP 14



16 12PCS


STEP 15




11		4PCS
12		8PCS
13		8PCS
14		48PCS

Assembly Instructions

STEP 16




STEP 17




Assembly Instructions

Finish!




HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw
clockwise to move the door further away from
the side of the cabinet
anticlockwise to move the door closer to the
side of the cabinet



② ④ Height adjustment

While supporting the weight of the door, turn the
screws
clockwise to move the door up
anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the
cabinet is too small, and the door may not close
fully. Turn the screw
clockwise to decrease the gap between the
door and the cabinet
anticlockwise to increase the gap between the
door and the cabinet

