







ASSEMBLY INSTRUCTION















P 2

 x^2 


x1



x2

 x^2  x^2  x^2 


1



E	x16
	
M4x14 mm	


H	x4
	

2



C	x16
	
M6x12 mm	

3





Please note: Screw #B must be fully tightened. If it is not fully tightened, this table cannot be folded.

When assembling the part #5, the sliding rail of the part #6 must be fully extended.

B	x4
	
M6x8 mm	


4



A	x16
	
Ø7x48 mm	

F	x16
	
Ø18mm	


5



D	x12
	
M6x25 mm	

F	x12
	
Ø18mm	


6



E	x32
	
M4x14 mm	


G	x8
	

7



J	x6
	
30mm	

8



9

