


Assembly Instruction

———— SFB148 ————



General Guidelines

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.


Notes

- The product is intended for indoor use only. The product must be assembled and used in accordance with the provisions of the manual. Personal injury and/or damage to product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The seller does not assume any responsibility or liability with respect to any injury/damage caused by incorrect assembly or improper use.
- Avoid long-term exposure to humid environments to prevent mildew.
- Keep the product away from fire sources and high temperatures. Do not expose the product to direct sunlight.
- Do not place any hot objects on the surface of the product.
- If there are any defective or missing parts after unpacking, please cease assembly immediately and contact us.
- Please assemble the item on a spacious surface and do not place the unwrapped product directly on the ground to avoid product damage.
- Please do not stand or sit on the wooden boards.
- Please wear gloves during the assembly and/or disassembly process to avoid scratches from any sharp edges.
- Please match the corresponding part and fitting based on the part number in the manual.
- If the part does not match with the fitting, please check the piece as specified in this manual.
- During assembly, first loosely align all screws with the corresponding pre-drilled holes and then tighten the screws one by one.
- Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity.
- If you accidentally spill water or another liquid on the surface, immediately wipe clean with a dry towel.
- Please keep the product away from sharp, pointed objects and corrosive substances to prevent product damage.
- Please place this item on level, solid ground during use.





Warnings















- During assembly, keep all small parts out of the reach of children. It may be fatal if swallowed or inhaled.
- Children should not climb or play on the product in order to avoid tipping over the furniture and causing serious injury.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (film, plastic bags, foam, etc.) away from babies and children.
- Keep sharp objects and corrosive items away from the product to avoid any damage or injury.
- Do not shake or move violently during use to avoid tipping over the product.

Parts List(EN)/Teile Liste(DE)














Parts List(EN)/Teile Liste(DE)



<div>①</div> <div></div> <div>2PCS</div>	<div>②</div> <div></div> <div>2PCS</div>		
<div>③</div> <div></div> <div>2PCS</div>	<div>④</div> <div></div> <div>2PCS</div>	<div>⑤</div> <div></div> <div>2PCS</div>	
<div>⑥</div> <div></div> <div>2PCS</div>	<div>⑦</div> <div></div> <div>4PCS</div>	<div>⑧</div> <div></div> <div>2PCS</div>	
<div>⑨</div> <div></div> <div>1PCS</div>	<div>⑩</div> <div></div> <div>1PCS</div>	<div>⑪</div> <div></div> <div>2PCS</div>	<div>⑫</div> <div></div> <div>1PCS</div>
<div>⑬</div> <div></div> <div>1PCS</div>	<div>⑭</div> <div></div> <div>1PCS</div>		


Parts List (EN) / Teile Liste (DE)




<p>A</p>  <p>L:37</p> <p>48+2PCS</p>	<p>B</p>  <p>Ø15*9.5</p> <p>48+2PCS</p>	<p>C</p>  <p>Ø6*30</p> <p>32+2PCS</p>
<p>D</p>  <p>Ø35mm</p> <p>8PCS</p>	<p>E</p>  <p>Ø3.5*12</p> <p>48+2PCS</p>	<p>F</p>  <p>8+1PCS</p>
<p>H</p>  <p>48+2PCS</p>		

Assembly Stpes (EN) /Montageschritte (DE)

Step 1






Step 2



Assembly Steps (EN) /Montageschritte (DE)



Step 3

x2



Step 4

x2







	Bx18pcs
	Cx12pcs
	Ax18pcs

Assembly Steps (EN) /Montageschritte (DE)

Step 5



x2




	Ex36pcs
	Dx6pcs



Step 6

x2




	Fx6pcs
---	--------

Step 7




Step 8



	Bx6pcs
	Cx4pcs
	Ax6pcs


Step 9




	Bx6pcs
	Cx4pcs
	Ax6pcs

Assembly Stpes (EN) /Montageschritte (DE)


Step 10




Step 11



Step 12




Step 13




The ways to adjust the door

- Before adjusting the hinge, please check whether the cabinet is skewed.
- If the skew can not be repaired, please remove the anti-tipping device first, then adjust the cabinet to vertical position.
- Please adjust the hinge with the door open.
- Please operate it with more than 2 people, one person holds the door and the other one adjusts the screw.


Components Name



Obvious gaps between doors or Doors don't look closed



- 1 Turn "internal & external screw" to the right can make the door approach inside. Please adjust the doors little by little.




※ If the 2 doors are overlap, please turn the "internal & external screw" to the left.

When door is crooked




Please take the following steps to adjust first.

- 1 Rotate the "front and rear screws" to the left




※ After adjusting the "front and rear screw", the door still does not change, please turn the "internal & external screw" to the right slightly.


- 2 Push the door to the cabinet




- 3 Rotate the "front and rear screws" to the right




When door is leaning




- 1 Turn "internal & external screw" to the left can make the top of the door tilted outward.




Protruding to the upside




- 1 Turn "internal & external screw" to the left can make the bottom of the door tilted outward.




When the door is higher on top




- 1 Turn "up & down screw" to the left



- 2 Lower the door's height so that 2 doors are of the same height.



- 3 Turn "up & down screw" to the right



※ If the door is lower on bottom, please lift up the left door slightly on step 2