

# INSTRUCTION MANUAL

MODEL: B1510-2GSM-X

Edition:20250613489Z

# ASSEMBLY GUIDE

Congratulations, you now have a new function sofa with massage.

Before enjoy the comfort chair, you have to put it together. This Assembly Guide will take you through the basic assembly process. To make sure your assembly goes smoothly, please follow the assembly instructions, and especially the important safety information.

Also, while it is possible to assemble the chair on your own, having a second person to help you makes it even easier.

Have any question about parts, assembly steps or operation of the chair, just be free to contact us.

Please provide us with the following information to make sure that we'll give you an effective solution much faster:


1. Order Number
2. Detailed description of the order issue you encounter
3. Some pictures or video that might be of help to display your problem

Yours sincerely,


Customer Service Team

# PACKAGE LIST


02




Seat cushion (A) \*1




BACK (B) \*1



Seat frame (C) \*1




F (R) (F) Armrest cover




F (L) (F) Armrest cover




Connector \*4




Massager remote control board (G) \*1




Massager power supply (H) \*1




Back frame \*1




Bolts M6\*16mm (N) \*8+1(extra)



Spanner (O) \*1



Glove \*1




Cup holder \*2


# PACKAGE LIST

03

STEP 1: Flip the seat frame over with the footrest facing upwards, Pull the footrest with your hand, Then remove the compressed seat cushion and accessory box from the frame.




STEP 2: Open the compression bag and remove the soft bag and Gently pat the soft package with your hand.




# ASSEMBLY INSTRUCTION

04

STEP 3: Open the compression bag and remove the soft bag, gently pat them.




STEP 4: Open the compression bag and remove the soft bag, gently pat them..




# ASSEMBLY INSTRUCTION

STEP 5: Fix the connector to the inside of the armrest with M6x16mm bolts, paying attention to the direction of fixing the connector.




STEP 6: Fix the connector to the inside of the armrest with M6x16mm bolts, paying attention to the direction of fixing the connector.




# ASSEMBLY IN STRUCTION

STEP 7: Install the armrest cup holder.




STEP 8: Insert arms so that they can fit into the seat, you will hear a "click" when they are engaged.




# ASSEMBLY IN STRUCTION

07

STEP 9: Pull the pull ring on the side of the seat and turn on the rack. Put the seat cushion to the corresponding position and stick the magic sticker to fixed seat cushion.




STEP 10: Open the compression bag and remove the soft bag and Gently pat the soft package with your hand.




# ASSEMBLY IN STRUCTION

08


STEP 11 Zip the backpack and back frame, and then connect the backpack and back frame with velcro.




STEP 12: Plug the back pad into the seat frame, and then connect the massager line white and white, red and red, black and power lines, and the massage line with the hand controller.




STEP 13:Stick the velcro from the back frame to the seat frame.



# ASSEMBLY IN STRUCTION




Pull the handle to spread out the SOFA



Pull back the SOFA with your legs

*Congratulations! You've assembled*  
**Your Sofa!**




**Note:** Since the cushion is packed in compression, after the product is installed, you need to tap and adjust the cushion which can help restore fullness. After two days, you will get an Overstuffed Recliner as picture shows.

# MASSAGE CHAIR


READ ALL INSTRUCTIONS  
BEFORE USING THE ITEM

## REMOTE CONTROL

Function of remote



USB



## I 、 Specifications of power adapter

Power on in standby state. The user can realize the function through the hand controller control Input :AC 100-240V, 50Hz/60HZ; Output: DC 12V. 4A.

## II 、 Function details

- 1.Master power button: Press to activate the kneading function of the kneading machine/heating plate heating function (default kneading intensity M of the kneading machine at startup/set shutdown time of 10 minutes), press again to turn off the kneading function of the kneading machine/heating plate heating function (cycle)
- 2.Click on three timing cycles (10/20/30 minutes)
- 3.Kneading intensity key: Press and press to cycle and switch the kneading intensity of the kneading machine. By default, M medium mode, M mode →H mode →L mode (cycle) upon startup
- 4.Click the heating switch
- 5.Kneading on key: Press and press to activate the kneading function of the kneading machine, and press and press again to turn it off
- 6.Kneading function of the kneading machine (cycle)
- 7.USB reconnection port
- 8.Intensity indicator light
- 9.Time light

## III 、 Product features

- 1.Kneading with a 4-point kneading machine
2. 1-way heating plate
3. Three-stage scheduled shutdown duration selection
4. Three-speed kneading machine kneading intensity selection
5. Support USB charging 5V 2.0A

## Warnings

1. Sit down in the chair gently. To avoid tipping over, do not throw yourself into the chair. Move the chair into the reclining position slowly, making sure that no children or pets are in close proximity. Do not allow children to play on or around the chair, particularly when it is in an open position.
2. Close the recliner completely before getting out of it.
3. Never sit on the footrest when it is open, even if it is a child.
4. To eliminate the risk of tipping over, do not sit on the arms or footrest of the chair.
5. This chair is designed to be used by 1 adult at a time.
6. Please forbid people with the following ailments from using this sofa: Those people with severe symptoms of heart disease, high blood pressure, cerebral thrombosis and others who are sensitive to heat or completely insensitive to heat, those with brittle bones or have issues with waist support pregnant women, children and others where it has been determined they are not suitable to use this product under the guidance of doctors.
7. To fully recline the sofa, ensure the sofa well, you need to put the sofa at least 19 inches away from the wall or any other obstacle.
8. Product cannot touch water, fire, etc. Product can also not come in contact with sharp objects (knives, nails, etc.)

## Maintenance Manual Instructions

1. To avoid dropping, you should carry the sofa carefully.
2. If you find dirt and or stains on the chair, spray the sofa with a sofa specific cleaner then use a sponge or cloth to wipe the dirt away. Do not use water, soapy water or cleaner with waxed wooden areas. Take care to wipe the sofa carefully and gently.
3. Do not put the sofa in an area with direct sunlight and do not put the sofa directly in front of an air conditioner, this will fade the upholstery and make it brittle.

## How to Disassemble

Please find a strong tool to prod the small piece of metal grooves, then the backrest will be pulled out. The tool is not included.

