


TV STAND

Assembly Instructions - Please keep for future reference



Dimensions

Width-102.91inch

Depth-14.96inch

Height-76.77inch



Be careful! At least two people are required



WARNING



This product is NOT a Clothing Storage Unit (CSU). DO NOT use it for clothing storage. Improper use may cause furniture tipover.

Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING
In order to help prevent overturning –
please follow these instructions








To help prevent product toppling over please follow the below steps:-

- Use the anti tip stap or wall fixing method provided (if applicable)
- Do not allow children to climb or hang on the furniture
- Do not open more than one drawer at a time
- Do not place heavy items in the top drawers
- Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Components - Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A</p>  <p>Cam Bolt 111+2pcs</p>	<p>B</p>  <p>Cam Lock 111+2 pcs</p>	<p>C</p>  <p>Sticker 36pcs</p>	<p>D</p>  <p>8x40 Dowel 63+2 pcs</p>
<p>E</p>  <p>5*40mm Screw 16pcs</p>	<p>F</p>  <p>#3.5x12mm Screw 64pcs</p>	<p>G</p>  <p>#3.5x40mm Screw 8pcs</p>	<p>H</p>  <p>#3.5x15mm Screw 72pcs</p>
<p>I</p>  <p>Nail leg 14pcs</p>	<p>J</p>  <p>Metal shelf support 32pcs</p>	<p>K</p>  <p>Joint nut 14pcs</p>	<p>L</p>  <p>Screw 14pcs</p>
<p>M</p>  <p>Hinges 12pcs</p>	<p>N</p>  <p>300mm Runner 2set</p>	<p>O</p>  <p>4*60 Srew 3 pcs 6*60 Wall plug 3 pcs</p>	<p>P</p>  <p>M4*18 Screw 10pcs</p>
<p>Q</p>  <p>Handle 6pcs</p>	<p>R</p>  <p>Handle 2pcs</p>	<p>S</p>  <p>Anti-tip hardware 2set</p>	<p>T</p>  <p>Back panel clip 40pcs</p>
			


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.


4



Components - Parts


BOX:A **N721P413072**
WF320396

01




Top Panel (L&R)
466*380*152PCS

12




Top Panel (Center)
1696*380*30 1PC

22




Leg Panel (Center)
1695*80*15 1PC

24




Box Side Panel (L1)
1000*190*15 1PC

25




Box Side Panel (R1)
1000*190*15 1PC

27




Box Side Panel (L2)
1000*190*15 1PC

28




Box Side Panel (R2)
1000*190*15 1PC

29




Box Side Rail(L&R)
1000*50*15 2PCS

30




Box Back Panel (L&R)
1008*208*3 4PCS

32




Box Top Panel
1696*222*30 1PC

33




Box Bottom Panel (Center)
1696*190*15 1PC

38




Drawer Front
410*194*15 1PC

39



Drawer Back
351.8*130*15 1PC



















41



Drawer Side (R)
300*130*15 2PCS



















Components - Parts

BOX:B N721P413074
WF320397


<p>03</p>  <p>Side Panel (L1) 900*350*301PC</p>	<p>04</p>  <p>Side Panel (R1) 900*350*15 1PC</p>	<p>05</p>  <p>Side Panel (L2) 900*350*15 1PC</p>
<p>06</p>  <p>Side Panel (R2) 900*350*30 1PC</p>	<p>07</p>  <p>Back Panel (L&R) 813*208*3 4PCS</p>	<p>10</p>  <p>Leg Panel (L) 451*80*15 1PC</p>
<p>11</p>  <p>Leg Panel (R) 451*80*15 1PC</p>	<p>13</p>  <p>Bottom Panel (Center) 1665*350*15 1PC</p>	<p>14</p>  <p>Side Panel (L3) 715*350*15 1PC</p>
<p>15</p>  <p>Side Panel (R3) 718*350*15 1PC</p>	<p>16</p>  <p>Center Panel 638*350*30 1PC</p>	<p>17</p>  <p>Back Panel (Center) 324*840.5*3 2PCS</p>
<p>29</p>  <p>Box Side Rail(L&R) 1000*50*15 2PCS</p>	<p>34</p>  <p>Box Side Panel 208*190*15 1PC</p>	<p>37</p>  <p>Box Back Panel 1665*208*15 1PC</p>
<p>38</p>  <p>Drawer Front 410*194*15 1PC</p>	<p>45</p>  <p>Back Panel (Center) 324*825.5*3 2PCS</p>	

Components - Parts


BOX:C N721P413075
WF320398





<p>02</p>  <p>Bottom Panel (L&R) 406*350*15 2PCS</p>	<p>08</p>  <p>Front Bone (L&R) 406*60*15 2PCS</p>	<p>09</p>  <p>Shelf Panel (L&R) 404*324*15 2PCS</p>
<p>18</p>  <p>Front Bone (Center) 817.5*60*15 2PCS</p>	<p>19</p>  <p>Shelf Panel (Center L) 830.5*324*15 1PC</p>	<p>20</p>  <p>Shelf Panel (Center R) 815.5*324*15 1PC</p>
<p>21</p>  <p>Leg Center 350*65*15 1PC</p>	<p>23</p>  <p>Box Top Panel (L) 222*453*30 1PC</p>	<p>26</p>  <p>Box Top Panel (R) 222*453*30 1PC</p>
<p>31</p>  <p>Box Shelf Panel (L&R) 405*171*15 4 PCS</p>	<p>35</p>  <p>Box Side Panel 208*190*15 1PC</p>	<p>36</p>  <p>Box Center Panel 208*173*15 2PCS</p>
<p>39</p>  <p>Drawer Back 351.8*130*15 1PC</p>	<p>40</p>  <p>Drawer Side (L) 300*130*15 2PCS</p>	<p>42</p>  <p>Drawer Bottom 361.8*295*3 2PCS</p>
<p>43</p>  <p>Door Panel 586*410*15 3PCS</p>	<p>44</p>  <p>Door Panel 586*410*15 3PCS</p>	 <p>Hardware box</p>

Assembly Instructions





2 Height Options Of The Top Bridge: The top bridge can be installed at the same height as or higher than the height of the cabinets on both sides.






x2


STEP 1




Please turn the board over

(A) 
Cam Bolt 25pcs


(D) 
8x40 Dowel 17 pcs




STEP 2





STEP 3





<p>(A) </p> <p>Cam Bolt 7pcs</p>	<p>(D) </p> <p>8x40 Dowel 23pcs</p>
--	---

STEP 4



<p>(A) </p> <p>Cam Bolt 15pcs</p>	<p>(D) </p> <p>8x40 Dowel 9pcs</p>
---	--

STEP 5






Cam Bolt 40pcs





8x40 Dowel 4pcs


STEP 6




<p>F</p>  <p>#3.5x12mm Screw 6pcs</p>	<p>N1</p>  <p>CR</p> <p>300mm Runner 2pcs</p>
---	---

STEP 7



<p>F </p> <p>#3.5x12mm Screw 6pcs</p>	<p>N1  CL</p> <p>300mm Runner 2pcs</p>
---	---

STEP 8






Cam Lock 2 pcs




5*40mm Screw 2pcs

STEP 9




(B) 
Cam Lock 8 pcs

STEP 10




STEP 11



① 

Nail leg 6 pcs




STEP 12



Please stand the cabinet upright before proceeding to the next step of installation.




Be careful! At least two people are required



(B) 
Cam Lock 14 pcs

STEP 13




J







Metal shelf support 8ps

STEP 14








STEP 15





(B) 
Cam Lock 12pcs

STEP 16




STEP 17








① Ⓜ
Nail leg 8 pcs

STEP 18



Please stand the cabinet upright before proceeding to the next step of installation.




B

Cam Lock 8pcs

J


Metal shelf support 8ps




Be careful! At least two people are required

STEP 19


X2




1






2



3



4




G 
#3.5x40mm Screw 8pcs

B 
Cam Lock 8pcs


P 
M4*18 Screw 4pcs

R 
Handle 2pcs


STEP 20 X2





(F) 
#3.5x12mm Screw 12pcs

N2  **DR**
DL
300mm Runner 4pcs

STEP 21



STEP 22



(H)




#3.5x15mm Screw 24pcs

(M)






Hinges 12pcs

STEP 23



<p>Ⓟ</p>  <p>M4*18 Screw 6pcs</p>	<p>Ⓠ</p>  <p>Handle 6pcs</p>
--	---

STEP 24






(B)



Cam Lock 8pcs

STEP 25





(B)





Cam Lock 8pcs


STEP 26




STEP 27



STEP 28







STEP 29



STEP 30




Be careful! At least two people are required



Cam Lock 8pcs

STEP 31




J 
Metal shelf support 16pcs

STEP 32



Be careful! At least two people are required



(K)




Joint nut 6pcs

(L)



Srew 6pcs

STEP 33








(H)




#3.5x15mm Screw 48pcs

STEP 34




HINGE ADJUSTMENT GUIDE

It may be necessary to adjust the hinges so that the doors align. Use the instructions below as a guide.




Loosen the middle screw as shown by turning clockwise or anti-clockwise as needed.

To adjust the door horizontally



Loosen one screw at rear hole and unscrew the other three screw as shown to move up or down vertically as needed. Screw back the other screw once the desired position for the door are satisfied.


To adjust the door vertically



Loosen the rear screw by turning clockwise or anti-clockwise and move the position of the door to front or back as needed.

To adjust the gap from the door to the main frame

STEP 35






Cam Lock 12pcs






5*40mm Screw 6pcs

STEP 36




<p>(B)  Cam Lock 4pcs</p>	<p>(E)  5*40mm Screw 8pcs</p>
--	--

STEP 37




<p>(T) </p> <p>Back panel clip 40 pcs</p>	<p>(F) </p> <p>#3.5x12mm Screw 40pcs</p>
<p>S2 </p> <p>Screw x 2</p>	<p>S4 </p> <p>Wall support x 2</p>

STEP 38



 S1 Screw x 2	 S3 Wall plug 2 pcs	 S4 Wall support x 2
--	--	---

STEP 39









 S5 Cable tie 2 pcs
--

STEP 40

OPTIONS 1

There is 2 ways of installation.





 Joint nut 8pcs	 Srew 8pcs
 Wall plug x 3	 Screw x 3

 Be careful! At least two people are required


STEP 41

OPTIONS 2

Can be fix on wall separately on height needed.




O1




Screw x 3

O2





Wall plug x 3



Be careful! At least two people are required

Finish

OPTIONS 1



C



Sticker 36pcs

OPTIONS 2

