

# Assembly Instructions

**Caution : You must read these Assembly Instructions  
before you proceed**

## Care & Maintenance



● Not for commercial use. For residential use only.



● Do not put hot items directly on furniture surface.



● Do not clean furniture with harsh cleansers or polish.



● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



● Children should not climb or jump on the furniture.



● Do not write on furniture without a padded barrier to protect the surface.



● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.




● Stains may be removed with mild soap solution and damp cloth.



● Dust and pick-up spills using a clean, non-colored, lint- free cloth.

Please look in the **Seat Panel** for hardware packs.

## CLUB CHAIR










**CAUTION:** This Club Chair is NOT a TOY.





Keep your child/ children at bay during the assembly process.

Whenever lifting or moving the Club Chair and to prevent any damage to it, two adults may be needed to execute these actions.

## Part List


Label	Picture	Description	QTY
A		Backrest Panel	1
B		Right Leg Panel	1
C		Left Leg Panel	1
D		Support Backrest Panel	1
E		Seat Panel	1
F		Seat Cushion	1
G		Back Cushion	1

## Hardware

Label	Picture	Description	QTY
①		Screws (M6x15mm)	3
②		Screws (M6x75mm)	3
③		Bolt (M6x50mm)	5
④		Allen Wrench	1

## Assembly Preparation


### Before Beginning Assembly:



- Read instructions, cover to cover-
- Have 2 adults on hand for assembly-
- Do not assemble on flooring or carpet-
- Assemble on a clean non-marring surface (packing foam)-
- Save all packaging until finished-


## Assembly Steps

### Overview




This Club Chair has multiple parts and may require up to 45 minutes to assemble. To give you an overview of the Club Chair parts, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

### Step 1




Unpack and place all parts on a clean, non-marring surface.

## Step 2



Place Seat Panel (E) and Right Leg Panel (B) as shown in the picture above onto a clean, non-marring surface. Attach the Right Leg Panel (B) to the Seat Panel (E) by using Screw (2) and Allen Wrench (4) as shown above. **Do not fully tighten the Screws at this time.**

## Step 3




3.1) Attach Support Backrest Panel (D) to the Right Leg Panel (B) from step 2 by using Screws (1) and Allen Wrench (4) as shown above

3.2) Attach the Right Leg Panel (B) and the Seat Panel (E) to the Backrest Panel (A) by using Bolts (3) and Allen Wrench (4) as shown above.


**Do not fully tighten the Bolts and Screws at this time.**

## Step 4



Attach Left Leg Panel (C) to the Seat Panel (E) from step 3 by using Screw (2) and Allen Wrench (4) as shown above. **Do not fully tighten the Screws at this time.**

## Step 5




5.1) Attach Support Backrest Panel (D) from step 3 to the Left Leg Panel (C) from step 4 by using Screws (①) and Allen Wrench (④).

5.2) Attach the Left Leg Panel (C) and the Seat Panel (E) from step 4 to the Backrest Panel (A) by using Bolts (③) and Allen Wrench (④) as shown above.

**Do not fully tighten the Screws at this time.**

## Step 6



Turn the Club Chair right side up.

Inspect the Club Chair and make sure all parts are adequately connected.


In a sequential manner, tighten all Screws and Bolts at all joints.

**CAUTION : When tightening these screws and bolts, tighten sequentially.**

**DO NOT** tighten any screw or bolt fully and then move towards the next one. This could cause the frame to warp.

**WARNING!! IF THE CLUB CHAIR IS NOT STABLE , IT COULD LEAD TO DAMAGING THE PRODUCT.**

## Step 7



Place the Seat Cushion (F) and the Back Cushion (G) into the Club Chair, and affix the velcro straps around the Club Chair as shown above.

**Your Club Chair is ready to be used.**

**This Club Chair can only be used on a flat, level surface.**