












Assembly Instructions


Caution: You must read this before you proceed

Care & Maintenance





- 
 - Not for commercial use. For residential use only.
 - 
 - Furniture may scratch floors. We recommend using furniture pads to protect your floors.
 - 
 - Do not put hot items directly on furniture surface.
 - 
 - Do not clean furniture with harsh cleansers or polish.
 - 
 - Do not place furniture under direct sunlight.
 - 
 - Do not place furniture near heating or cooling vents.
 - 
 - Do not write on furniture without a padded barrier to protect the surface.
 - 
 - Do not place furniture outside . For indoor use only.
 - 
 - Stains may be removed with mild soap solution and damp cloth.
 - 
 - Children should not climb or jump on the furniture.
-
- 
 - Dust and pick-up spills using a clean, non-colored, lint-free cloth.



Please look in backrest for hardware packs and legs.

SOFA








Parts List












| Label | Picture | Description | QTY |
|-------|---|---------------|-----|
| A |  | Sofa Base | 1 |
| B |  | Sofa Backrest | 1 |
| C |  | Left Arm | 1 |
| D |  | Right Arm | 1 |

| | | | |
|---|---|--|---|
| E |  | Wooden Leg (With Plastic Gasket) | 4 |
| F |  | Middle Wooden Leg (With Plastic Gasket) | 1 |

Hardware List

| Label | Picture | Description | QTY |
|-------|---|----------------|-----|
| ① |  | Plastic Gasket | 3 |
| ② |  | Bolt(M8*60mm) | 15 |
| ③ |  | Washer | 15 |
| ④ |  | Spring Washer | 15 |
| ⑤ |  | Allen Wrench | 1 |

Assembly Preparation

| | | | |
|----------------------------------|---|--|--|
| Before Beginning Assembly: |      Ex4   ① x3  ② x15  ③ x15  ④ x15  ⑤ x | | |
|----------------------------------|---|--|--|



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Sofa has multiple parts and may require about 30 minutes to assemble. To give you an overview of the Loveseat parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Take the Sofa Base(A), Sofa Backrest(B), Left Arm(C), Right Arm(D) out from the carton and place them on a clean, non-marring surface.

Step 2




Take out the Legs Carton from the bottom of the Sofa Backrest(B).
Open the Legs Carton to take out the Wooden Legs(E)&(F) and Hardware.

Step 3



With assistance from your adult partner, hold up the Sofa Backrest(B).
Align the mounting brackets on both sides of the Sofa Backrest(B) with those on the Left Arm(C) and Right Arm(D).
Then slide Sofa Backrest(B) downward by hand to make sure it locks into place as pictured.

Step 4




Place the Sofa Backrest(B), Left Arm(C) and Right Arm(D) on a clean, non-marring surface.

With assistance from your adult partner, put the Sofa Base(A) between the Left Arm(C) and Right Arm(D) as a whole as picture.

Align the bolts holes on the both side of Sofa Base(A) with those on the Sofa Backrest(B), Left Arm(C) and Right Arm(D).

Make sure the bottom of the Sofa Base(A), Sofa Backrest(B), Left Arm(C) and Right Arm(D) at the same level.

Step 5




Open the back non-woven cover under Sofa Base(A).

Attach Sofa Base(A) to the Left Arm(C) and Right Arm(D) using Bolts(②), Spring Washers(④) and Washers(③) with Allen Wrench(⑤).

Please don't tighten the Bolts, just bolt them in half-way until all bolts are in, then tighten all the Bolts with the Allen Wrench(⑤).

Note: The bottom of the Sofa Base(A) frame must be aligned with the bottom of the Armrest.

Step 6



Insert the 6 Bolts(②) half-way until all Bolts are bolted in with Allen Wrench(⑤)


Using the Allen Wrench(⑤) to secure Sofa Base(A) to the front-bottom of Sofa Backrest(B) with the 6 Bolts(②), 6 Spring Rings(④) and 6 Washers(③).

Insert the 6 Bolts(②) half-way starting one by one as pictured.

Then tighten the 6 Bolts(②) with the Allen Wrench(⑤)."

Close the non-woven fabric under the Sofa Base(A) with Magic Tape.

Step 7



Install the 4 Wood Legs(E) and Middle Wooden Leg(F) at the bottom of the Sofa by placing one Gasket(①) on the threaded stem.



Tighten by turning the Leg clockwise.

Note: The use of Gaskets(①) are OPTIONAL and are especially useful to help alleviate slight wobbleness. Some Legs may need more than one Gasket whilst some Legs may not need any.

Step 8



Don't turn the sofa directly, you need to lift the sofa up then put it down gently (in order to make sure the Legs or Legs support are not be damaged by any incorrect operation.



Make sure all of the parts connected to the right position and strong enough.
Now your Sofa is ready for use.
This Sofa can only be used on a flat, level surface.