

Assembly Instructions


Caution : You must read this before you proceed

Care & Maintenance

- ⊘  ● Not for commercial use. For residential use only.
 - ✓  ● Furniture may scratch floors. We recommend using furniture pads to protect your floors.
 - ⊘  ● Do not put hot items directly on furniture surface.
 - ⊘  ● Do not clean furniture with harsh cleansers or polish.
 - ⊘  ● Do not place furniture under direct sunlight.
 - ⊘  ● Do not place furniture near heating or cooling vents.
 - ⊘  ● Do not write on furniture without a padded barrier to protect the surface.
 - ⊘  ● Do not place furniture outside . For indoor use only.
 - ⊘  ● Stains may be removed with mild soap solution and damp cloth.
 - ⊘  ● Children should not climb or jump on the furniture.
- ✓  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.




Please look in carton for hardware packs and legs.
Sets often ship in multiple boxes and may arrive a day or two apart.

SOFA



Parts List

N758P390340A N758P390341A N758P390342A


Label	Picture	Description	QTY
A		Left-hand Side	1
B		Armless Chair	1
C		Right-hand Side	1
D		Ottoman	1
E		Legs	16

Assembly Preparation

Before Beginning Assembly :




A




B



C



D



E



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-



Assembly Steps

Overview




This Sofa has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the sofa parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1





Unzip the bottom packet to take out the legs inside.



Unpack and place all parts on a clean, non-marring surface and unfold the all cushions. Take out the 4 Legs(E) each from bottom pocket of Left-Hand Side(A), Armless Chair(B), Right-Hand Side(C) and Ottoman(D) as above picture shown on. Remove the cap on leg nolt before assembling, then rotating clockwise the legs(E) to attach them to the bottom pocket of Left-Hand Side(A), Armless Chair(B), Right-Hand Side(C) and Ottoman(D).

Removed the bottom cover of the legs to prevent slipping.

Step 2




Interlocking Brackets

Turn out the interlocking bracket on bottom of Left-Hand Side(A),align and insert it to the socket on the left bottom of Armless Chair(B) to connect the Left-Hand Side(A) and Armless Chair(B) as above picture shown on.

Repeat the same step to attach Armless Chair(B) to Right-Hand Side(C).

Step 3



Adjustable legs height to achieve balance

Place the ottoman(D) on left side or right side as you like.Your sofa is ready for use.

If the sofa wobbles adjust the height of legs until the sofa is level.

This sofa can only be used on a flat,level surface.