

Assembly Instructions

Caution : You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.




- Children should not climb or jump on the furniture.





- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in boxes for hardware packs and legs.

ACCENT CHAIR



Parts List


Label	Picture	Description	QTY
A		Backrest	1
B		Seat	1
C		Front Leg	2
D		Back Leg	1

Hardware

Label	Picture	Description	QTY
①		Bolt (M8X40mm)	5
②		Bolt (M8X30mm)	4
③		Spring Washer	5
④		Flat Washer	8
⑤		Allen Wrench	1

Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-

Assembly Steps


Overview



This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Friendly reminder: Tighten all the screws after all holes are installed.

Step 1




Open the carton, and place all parts on a clean, non-marring surface.

Take out Seat(B)

Unzip the bottom and expose the frame.

Step 2




Take out Back Leg(D)

Align the 4 holes of Leg(D) with the 4 exposed holes on the seat as shown.

Insert Bolt(1) ,Spring Washer(3) and Flat Washer(4) into the inside of the seat frame, with Allen Wrench(5) to tighten it.

Step 3




Take out Backrest(A)

Align the holes at the bottom of the backrest with the holes on the top of the back legs.

Use Bolt(2) and Flat Washer(4) with Allen Wrench(5) to tighten it.

Step 4




Zip up the bottom.

Then take out Front Leg(C).

Insert the threaded rods on the legs into the mounting holes on the bottom, then tighten them by hand.

Step 5



Place the Chair right side up and tested for stability.

Fully Tighten all the bolts.

Your Chair is ready for use.

This CHAIR can only be used on a flat, level surface.