

Assembly Instructions

Caution : You must read this before you proceed

Care & Maintenance


- ⊘  • Not for commercial use. For residential use only.
- ✓  • Furniture may scratch floors. We recommend using furniture pads to protect your floors.
- ⊘  • Do not put hot items directly on furniture surface.
- ⊘  • Do not clean furniture with harsh cleansers or polish.
- ⊘  • Do not place furniture under direct sunlight.
- ⊘  • Do not place furniture near heating or cooling vents.
- ⊘  • Do not write on furniture without a padded barrier to protect the surface.
- ⊘  • Do not place furniture outside . For indoor use only.
- ⊘  • Stains may be removed with mild soap solution and damp cloth.
- ⊘  • Children should not climb or jump on the furniture.





- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in Chair for hardware packs and legs.


Dining Chair






Parts List

Label	Picture	Description	QTY
A		Seat	1
B		Leg Frame	1

Hardware

Label	Picture	Description	QTY
①		Bolt(M6*30mm)	5
②		Washer (M6*Φ16mm)	5
③		Allen Wrench(M4)	1

Assembly Preparation

Before Beginning Assembly:				
	 ①x5	 ②x5	 ③ x1	 ③x1



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Dining Chair has multiple parts and may require up to 15 minutes to assemble. To give you an overview of the Dining Chair, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




A



B

Place the Seat(A), Leg Frame(B), and Left a clean, non-marring surface.


Step 2



Position the Seat(A) (bottom-up) as shown above, then attach Leg Frame(B) the Seat(A) with the Bolts(①), the Washers(②), and Allen Wrench(③).


Note: Once the assembly is completed, proceed to tighten all bolts sequentially.

Step 3



Adjust the Pre-installed Levelers at the bottom of the Legs Frame(B) until the Dining Chair is level with the ground.

Step 4



Your Dining Chair is ready for use.

This Dining Chair can only be used on a flat, level surface.